

MONTAGEANLEITUNG

Wandeinbauset S AP



Allgemein

Bezeichnung: ekey Wandeinbauset S AP
Art. Nr.: 101 500

Abmessungen (BxHxT) in mm

Unterputzgehäuse: 103 x 130 x 90
Frontgehäuse: 112 x 140 x 78

Material

Frontgehäuse: Edelstahl gebürstet

Montage

Bevor Sie mit der Montage beginnen können, ist eine entsprechende Ausnehmung in der Höhe von ca. 135 cm (Unterkante des Unterputzgehäuses) im Mauerwerk notwendig.

- Nachdem die optimale Montagehöhe ermittelt wurde, befestigen Sie das Unterputzgehäuse **(1)** im Mauerwerk mit Hilfe der 4 Haltetaschen **(2)**.
- Richten Sie die Montageplatte **(3)** des ekey Fingerscanners **(4)** auf der dafür vorgesehenen Metallplatte **(5)** des Wandeinbausets aus und schrauben diese fest.
- Stellen Sie die korrekte Verkabelung her (siehe Verkabelungsplan).
- Setzen Sie den ekey Fingerscanner **(4)** nun auf die Montageplatte **(3)** auf und fixieren diesen zusätzlich **(6)**.
- Positionieren Sie nun den ekey Fingerscanner aufputz samt Metallplatte in das Frontgehäuse **(7)** solange, bis Sie die Metallplatte am Frontgehäuse festschrauben können.
- Befestigen Sie das Frontgehäuse **(7)** samt Fingerscanner am Unterputzgehäuse. (siehe Abbildung links oben)



INSTALLATION MANUAL

In-wall mounting kit S WM



General information

Description: ekey In-wall mounting kit S WM
Part No.: 101 500

Dimensions (WxHxD) in mm

Back box: 103 x 130 x 90
Front panel: 112 x 140 x 78

Material

Front panel: brushed stainless steel

Installation

Prior to installation, prepare a corresponding recess in the masonry at approximately 135 cm above ground (lower edge of the flush housing).

- a. Once the required recess has been prepared, attach the flush-mounted back box **(1)** in the brickwork using the 4 retaining latches **(2)**.
- b. Align the mounting plate **(3)** of the finger scanner **(4)** on the accompanying metal plate **(5)** and tighten the screws firmly.
- c. Establish correct wiring (refer to wiring diagram).
- d. Position the ekey finger scanner **(4)** on the mounting bracket **(3)**. Fix it via the security screw on the bottom side of the scanner **(6)**.
- e. Continue to align the ekey finger scanner and the metal plate to the front panel **(7)**, until you can screw the metal plate to the front panel
- f. Attach the front panel **(7)** together with the ekey finger to the back box. (see illustration in the upper left hand corner)

