


# HC1-KNX









- ES NOTAS DE INSTALACIÓN:**
1. Seleccionar la altura de instalación de forma que permita línea de visión directa
  2. No instalar en lugares donde la luz solar incida directamente
  3. Temperatura ambiente de funcionamiento: 0-50 °C

- EN INSTALLATION NOTES:**
1. Select installation height to allow for direct line of sight
  2. Do not expose to direct sun light
  3. Operating temperature (ambient): 0-50 °C

- FR NOTES D'INSTALLATION:**
1. Sélectionnez la hauteur d'installation de façon qu'elle permette ligne de visée directe
  2. Ne pas exposer directement au soleil
  3. Température ambiante de fonctionnement: 0-50 °C

- DE INSTALLATIONSANMERKUNGEN:**
1. Wählen Sie eine Installationshöhe, die eine direkte Blicklinie ermöglicht
  2. Installieren Sie dieses Produkt nicht im direkten Sonnenlicht
  3. Betriebsumgebungstemperatur: 0-50 °C



CLICK !