


BSP125 Network Streaming Speaker

Owner's Manual



BLUESOUND
PROFESSIONAL

IMPORTANT SAFETY INSTRUCTIONS

- **Read instructions** - All the safety and operating instructions should be read before the product is operated.
- **Retain instructions** - The safety and operating instructions should be retained for future reference.
- **Heed Warnings** - All warnings on the product and in the operating instructions should be adhered to.
- **Follow Instructions** - All operating and use instructions should be followed.
- **Cleaning** - Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a dry cloth for cleaning.
- **Attachments** - Do not use attachments not recommended by the product manufacturer as they may cause hazards.
- **Water and Moisture** - Do not use this product near water-for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.
- **Accessories** - Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
-  **Cart** - A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.
- **Ventilation** - Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
- **Power Sources** - This product should be operated only from the type of power source indicated on the marking label and connected to a MAINS socket outlet with a protective earthing connection. If you are not sure of the type of power supply to your home, consult your product dealer or local power company.
- **Power-Cord Protection** - Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.
- **Mains Plug** - Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- **Outdoor Antenna Grounding** - If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.
- **Lightning** - For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
- **Power Lines** - An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
- **Overloading** - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- **Flame Sources** - No naked flame sources, such as lighted candles, should be placed on the product.
- **Object and Liquid Entry** - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- **Headphones** - Excessive sound pressure from earphones and headphones can cause hearing loss.
- **Damage Requiring Service** - Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - When the power-supply cord or plug is damaged.
 - If liquid has been spilled, or objects have fallen into the product.
 - If the product has been exposed to rain or water.
 - If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
 - If the product has been dropped or damaged in any way.
 - When the product exhibits a distinct change in performance-this indicates a need for service.
- **Replacement Parts** - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
- **Battery Disposal** - When disposing of used batteries, please comply with governmental regulations or environmental public instruction's rules that apply in your country or area.
- **Safety Check** - Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- **Wall or Ceiling Mounting** - The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

WARNING



THE LIGHTNING FLASH WITH ARROWHEAD SYMBOL, WITHIN AN EQUILATERAL TRIANGLE, IS INTENDED TO ALERT THE USER TO THE PRESENCE OF UNINSULATED "DANGEROUS VOLTAGE" WITHIN THE PRODUCT'S ENCLOSURE THAT MAY BE OF SUFFICIENT MAGNITUDE TO CONSTITUTE A RISK OF ELECTRIC SHOCK TO PERSONS



THE EXCLAMATION POINT WITHIN AN EQUILATERAL TRIANGLE IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE LITERATURE ACCOMPANYING THE APPLIANCE.



CAUTION REGARDING PLACEMENT

To maintain proper ventilation, be sure to leave a space around the unit (from the largest outer dimensions including projections) than is equal to, or greater than shown below.

- Left and Right Panels: 10 cm
- Rear Panel: 10 cm
- Top Panel: 10 cm

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

The apparatus should only be used in moderate climates.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

CAUTION

- Changes or modifications to this equipment not expressly approved by Bluesound Professional for compliance could void the user's authority to operate this equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - 1 this device may not cause harmful interference, and
 - 2 this device must accept any interference received, including interference that may cause undesired operation.
- This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
 - 1 This device may not cause interference.
 - 2 This device must accept any interference, including interference that may cause undesired operation of the device.
- To prevent electric shock, match wide blade of plug to wide slot, fully insert.
- Marking and rating plate can be found at the bottom enclosure of the apparatus.
- To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.
- Mains plug is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.
- Operating temperature: 0-35 degrees Celsius

RESPONSIBLE PARTY

Lenbrook International
 633 Granite Court
 Pickering, ON L1W 3K1
 Canada
 Tel: 1 905 8316555

MPE REMINDER

To satisfy FCC/IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

IF IN DOUBT CONSULT A COMPETENT ELECTRICIAN.



This product is manufactured to comply with the radio interference requirements of EEC DIRECTIVE 2004/108/EC.

NOTES ON ENVIRONMENTAL PROTECTION



At the end of its useful life, this product must not be disposed of with regular household waste but must be returned to a collection point for the recycling of electrical and electronic equipment. The symbol on the product, user's manual and packaging point this out.



The materials can be reused in accordance with their markings. Through re-use, recycling of raw materials, or other forms of recycling of old products, you are making an important contribution to the protection of our environment.

Your local administrative office can advise you of the responsible waste disposal point.

INFORMATION ABOUT COLLECTION AND DISPOSAL OF WASTE BATTERIES (DIRECTIVE 2006/66/EC OF THE EUROPEAN PARLIAMENT AND THE COUNCIL OF EUROPEAN UNION) (FOR EUROPEAN CUSTOMERS ONLY)



Pb

Batteries bearing any of these symbols indicate that they should be treated as "separate collection" and not as municipal waste. It is encouraged that necessary measures are implemented to maximize the separate collection of waste batteries and to minimize the disposal of batteries as mixed municipal waste.



Hg

Cd

End-users are exhorted not to dispose waste batteries as unsorted municipal waste. In order to achieve a high level of recycling waste batteries, discard waste batteries separately and properly through an accessible collection point in your vicinity. For more information

about collection and recycling of waste batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

By ensuring compliance and conformance to proper disposal of waste batteries, potential hazardous effects on human health is prevented and the negative impact of batteries and waste batteries on the environment is minimized, thus contributing to the protection, preservation and quality improvement of the environment.

WHAT'S IN THE BOX

Packed with your BSP125 you will find

- Two detachable mains power cord
- TOSLINK mini-adaptor
- Quick Setup Guide

SAVE THE PACKAGING

Please save the box and all of the packaging in which your BSP125 arrived. Should you move or otherwise need to transport your BSP125, this is by far the safest container to do so. We've seen too many otherwise perfect components damaged in transit for lack of a proper shipping carton, so please: Save that box

QUICK START

This simple guide will help you get started with your BSP125. Your BSP125 can be connected to your home network via **Wired** or **Wireless** connection.

IMPORTANT SETUP NOTES

- *Before setting up or making connections, ensure that the BSP125 and other devices to be connected to BSP125 are unplugged or powered down.*
- *Connect corresponding end of the supplied AC power cord to BSP125's AC mains input and the AC power cord's plug connected to mains power outlet.*
- *Tablets, smartphones and other applicable devices that support iOS (Apple) or Android operating system can be used as mobile device controller. These devices are not supplied with your BSP125.*
- *Download and install the corresponding "BluOS Controller" App for your device.*
- *The BluOS App is available as a Mobile App for Android, iOS, Kindle and Desktop App for Windows and macOS Computers.*
- *Mobile Apps are handled by the respective Application Store of the Mobile devices.*

WIRED CONNECTION

Using an Ethernet cable (not supplied), connect one end to BSP125's LAN port and the other end directly to your Wired network or router.

WIRELESS CONNECTION

The process is very easy but slightly differs between iOS (Apple) and Android devices. Follow below instructions for the smartphone or tablet that applies to you. Windows and Mac users please see the instructions under **Wireless Manual Setup** below.

ANDROID

- 1 Open App. The App may immediately prompt you saying "New Players detected"; select "Setup Now".
 - a If you are not prompted, open the Player Drawer by pressing the Home icon in the top right corner of the App.
 - b Scroll to the bottom and select "Add a Player" to launch the Easy Setup Wizard.
 - c Select your BSP125's unique network ID* from the Players detected Window.
 - d Select your Home Wi-Fi Network from the "Choose a Wi-Fi Network" drop down menu.
 - e If your Home Wi-Fi Network does not appear or is hidden, select "Manual SSID Entry". Enter network or applicable wireless network name.
 - f Select the "Network Security" your network uses.
- 2 Enter your home network's Wi-Fi Password in the field provided and select "OK".

- 3 Enter the "Player Name" you prefer your BSP125 to be customized for easier identification in the Player Drawer. Network setup connection proceeds automatically.
- 4 Network setup connection is completed when "All Done!" is shown in the App.

- * The BSP125's unique network ID is listed as the product name (i.e. BSP125) immediately followed by the last four digits in the MAC (Machine Access Control) address (example: BSP125-001A). The full 12-digit MAC address is printed on a sticker on the BSP125 rear panel.

iOS

- 1 Open App. Select Home icon in the top right corner of the App.
- 2 Scroll to the bottom and select "Add a Player" to launch the Easy Setup Wizard.
- 3 As illustrated, press the Home button and open the iOS Settings App to select the Wi-Fi network you will connect.
- 4 From the same iOS Settings App, select your BSP125's unique network ID*. Follow prompt instructions.
- 5 Return to BluOS App upon completion of the network setup connection.

If the above method does not work or if you are on a Windows PC or Apple Mac, **Wireless Manual Setup** can be undertaken.


WIRELESS MANUAL SETUP

- 1 Select your BSP125's unique network ID* from the Wi-Fi Setup connection settings menu of your tablet, smart phone or computer and join it.
- 2 "...Control Panel" menu window should automatically open. If not, open the web browser of your device and visit <http://10.1.2.3>
- 3 Select "Configure Wi-Fi" from the "...Control Panel" menu. Select your network or applicable wireless network name (SSID) from the "Configure Wireless" drop down menu.
- 4 Enter your network's Wireless Password (Passphrase, WEP/WAP key as applicable) in the field "Enter password or key (if protected)".
- 5 Select a "Player name" from the drop down list or use the on-screen keyboard to create a customized room name in the field "Custom name".
- 6 Select "Update" to save all your settings and complete the set up connection of your BSP125. Do not forget to go back to the Wi-Fi Settings section of your device to confirm that it is reconnected to the correct Wi-Fi network.

Your BSP125 is now connected to your Wi-Fi network and ready to be used with the BluOS controller App.

IMPORTANT!

Always ensure that your BSP125 is updated with the latest firmware. Go to the BSP125 product page at bluesoundprofessional.com for firmware update information.



ATTENTION!

Please ensure that the BSP125 is powered off or unplugged from the mains power outlet before making any connections. It is also advisable to power down or unplug all associated components while breaking any signal or AC power connections.

1 STATUS INDICATOR

Below is a table of the LED blink codes and their corresponding descriptions.

LED BLINK	CODE DESCRIPTION
Short blue flash, then red	Powering up, rebooting the unit
Alternate flashing red and green	Upgrading...
Flashing green	Connecting to network shares
Solid green	No network connection
Solid red	Cannot boot; drive error Upgrade mode
Red pulse	No internet gateway
Flashing red	Factory reset in progress
Solid white	Indexing
White pulse	Software update available
Solid blue	Connected to Network – ready to use with Bluesound App
Flashing blue	Mute mode

2 RESET

- Use the RESET button to switch BSP125 from operating mode to standby mode.

Switch from operating mode to standby mode: While at operating mode, press and hold RESET button until the illuminated blue LED status indicator turns off. BSP125 is not accessible via BluOS app while at standby mode.

Switch from standby mode to operating mode: While at standby mode, short press RESET button – LED status indicator will turn red to solid green if there is no wired internet connection or turn to red, flashing green and then solid blue with wired internet connection.

- Use the RESET button to restore BSP125 to its factory default settings.
- Factory Reset is recommended if your BSP125 is not functioning or internet firmware upgrade has failed. All customization, configuration, file shares and saved playlists will be lost. They have to be re-created once factory reset is completed.

FACTORY RESET PROCEDURE

- Disconnect AC power cord's plug from the mains power outlet.
- Press and hold rear panel RESET button and while doing so reconnect the AC power cord's plug to the mains power outlet.
- The front LED indicator turns red, immediately turns green and then back to red - do not release hold of the RESET button.
- After about 30 seconds of holding down the RESET button, the front LED indicator blinks red.
- Release the RESET button as soon as the front LED indicator blinks red.
- Factory reset is completed once the front LED indicator turns solid blue.

IMPORTANT NOTES

Releasing the RESET button at any time before the front LED indicator starts flashing red will cancel the factory reset and leave the BSP125 at Upgrade Mode. Just start again the procedure for Factory Reset.

3 MOUNTING THREAD

- Use this thread to mount BSP125 to a fixture or wall with the optional mounting bracket allowing for 40° swivel and 360° rotation of the speaker.

4 SERVICE/USB

- These USB port and tact switch are for servicing purposes only. Not for consumer use.

IDENTIFICATION OF CONTROLS

5 LAN

- LAN connection must be setup for wired connection to be established. Set up a Wired Ethernet broadband router with broadband internet connection. Your router or home network should have a built-in DHCP server to consummate the connection.
- Using a standard straight-through Ethernet cable (not supplied), connect one end of the Ethernet cable to the LAN port of your wired Ethernet broadband router and the other end to BSP125's LAN port.

NOTES

- *Bluesound Professional is not responsible for any malfunction of the BSP125 and/or the internet connection due to communication errors or malfunctions associated with your broadband internet connection or other connected equipment. Contact your Internet Service Provider (ISP) for assistance or the service bureau of your other equipment.*
- *Contact your ISP for policies, charges, content restrictions, service limitations, bandwidth, repair and other related issues pertinent to internet connectivity.*

6 OPTICAL IN/ANALOG IN

- Connect to corresponding output connectors of compatible audio devices using 3.5mm stereo cable (not supplied) or other applicable adaptors. This input also accepts headphone audio output from compatible devices.
- Install the supplied TOSLINK mini-adaptor to convert this input into a digital optical input.
- Access and playback analog or digital sources by selecting "Analog Input" or "Optical Input" from the BluOS App.

7 USB

- Connect to this USB port USB mass storage devices formatted as FAT32, NTFS or Linux ext4. The connected USB device appears as a Local Source (USB) in the BluOS App.
- Access and playback music stored in the connected USB device by selecting "USB" from the BluOS App.

8 AC MAINS INPUT

- The BSP125 comes supplied with two separate AC power cords. Select the AC power cord appropriate for your region.
- Before connecting the AC power cord plug to the mains power source, ensure that it is firmly connected to BSP125's AC Mains input socket first.
- Always disconnect the AC power plug from the mains power source first, before disconnecting the other end of the AC power plug from the BSP125's AC Mains input socket.

9 HEADPHONE OUT

- Connect to corresponding input ports of compatible audio devices using 3.5mm headphone cable (not supplied) or other applicable adaptors.
- The BSP125 speakers are automatically switched off when a headphone is plugged-in to this jack.

MAKING THE MOST OF YOUR BSP125

Download the BluOS Controller App from the respective App stores of Apple iOS devices (iPad, iPhone and iPod), Android devices, Kindle Fire and Windows or Mac desktops.

Launch the BluOS Controller App and explore everything from your streaming music services, internet radio stations, networked music collections and favorites with quick and easy single-search discovery.

Visit support.bluesound.com for more information about setup and operation guidelines of your BSP125.

AUDIO	
Rated power	25W at 0.03% THD+N
Total Harmonic Distortion (THD+N)	0.03% (ref. 20 Hz – 20 kHz at rated power)
Sample rate	32-192 kHz
Bit depth	16-24 bit
Supported audio file format ¹	MP3, AAC, WMA, OGG, FLAC, ALAC, WMA-L, MQA, WAV, AIFF
Supported cloud services ¹	Spotify, Amazon Music, WIMP, Qobuz, HIGHRESAUDIO, Deezer, Murfie, HDtracks, TIDAL, Napster, Microsoft Groove Music (with OneDrive), KKBox, Taihe Music ZONE, SoundMachine
Free internet radio ¹	TuneIn Radio, iHeartRadio, Calm Radio, Radio Paradise, Slacker Radio

CONNECTIVITY	
Input	Dual – Analog IN (3.5mm jack)/Optical IN (TOSLINK mini-adapter)
Output	Headphone OUT (3.5mm jack)
USB	1 x Type-A port for connection to USB memory stick (FAT32 or NTFS formatted) and supported peripherals 1 x Type-B (mini) for product servicing
Network	Gigabit, Ethernet RJ45 802.11 b/g/n WiFi
Album art	JPG
Supported operating systems	Music playback from network shares on the following desktop operating systems: Microsoft Windows XP, 2000, Vista, 7, 8 to current Windows Operating Systems and macOS versions ²
User interface	Free BluOS Controller App available for download from the respective App stores of Apple iOS devices (iPad, iPhone and iPod), Android devices, Kindle Fire and Windows or macOS desktops
Integration partners	Control4, RTI, Crestron, URC, push, iPort, ELAN, Lutron, Roon

GENERAL	
Processor	ARM® CORTEX™ A9 1 GHz
AC power supply	100-240V 50/60 Hz
Standby power	0.5 W
Gross dimensions (W x H x D)	125 x 183 x 100 mm 4 ¹⁵ / ₁₆ x 7 ¹ / ₄ x 3 ¹⁵ / ₁₆ inches
Unit weight	1.23 kg (2.7 lbs)

¹ Supported audio file format, cloud services and free internet radio are subject to change without notice.

² Compatibility to latest versions is subject to future software update.

Specifications are subject to change without notice. Check out www.bluesoundprofessional.com for updated documentation or latest information about BSP125.



www.bluesoundprofessional.com

©2019 BLUESOUND INTERNATIONAL
A DIVISION OF LENBROOK INDUSTRIES LIMITED

All rights reserved. Bluesound International, Bluesound Professional, Bluesound, the stylized wordmark and "B" logotype and all other Bluesound product names and taglines are trademarks or registered trademarks of Bluesound International, a division of Lenbrook Industries Limited.

No part of this publication may be reproduced, stored or transmitted in any form without the written permission of Bluesound International. While every effort has been made to ensure the contents are accurate at the time of publication, features and specifications may be subject to change without prior notice.

BSP125-OM-EN-V03 - NOV 2019