




KNX AQS/TH-UP gl CH

Combined indoor sensor

Item numbers 70646 (pure white), 70647 (jet black)



| | |
|--|-----------|
| 1. Description | 5 |
| 1.0.1. Scope of delivery | 5 |
| 1.1. Technical specifications | 6 |
| 1.1.1. Accuracy of the measurement | 6 |
| 2. Installation and commissioning | 7 |
| 2.1. Installation notes | 7 |
| 2.2. Installation position | 7 |
| 2.3. Composition | 8 |
| 2.3.1. Housing | 8 |
| 2.4. Assembly of the sensor | 8 |
| 2.5. Notes on mounting and commissioning | 9 |
| 3. Addressing of the device at the bus | 9 |
| 4. Disposal | 9 |
| 5. Transfer protocol | 10 |
| 5.1. List of all communications objects | 10 |
| 6. Parameter setting | 19 |
| 6.1. Behaviour on power failure/ restoration of power | 19 |
| 6.2. General settings | 20 |
| 6.3. Temperature value | 20 |
| 6.4. Temperature threshold values | 21 |
| 6.4.1. Threshold value 1, 2, 3 | 21 |
| 6.4.1.1. Threshold value | 21 |
| 6.4.1.2. Switching output | 22 |
| 6.4.1.3. Block | 22 |
| 6.5. Temperature PI control | 23 |
| 6.5.0.1. General control | 23 |
| 6.5.1. General set point values | 25 |
| 6.5.1.1. Set point Comfort | 26 |
| 6.5.1.2. Standby setpoint | 26 |
| 6.5.1.3. Eco setpoint | 27 |
| 6.5.1.4. Setpoint values for frost/heat protection (building protection) | 27 |
| 6.5.1.5. General control variables | 28 |
| 6.5.2. Heating control level 1/2 | 28 |
| 6.5.3. Cooling control level 1/2 | 30 |
| 6.6. Humidity measurement | 33 |
| 6.7. Humidity threshold values | 33 |
| 6.7.1. Threshold value 1, 2 | 33 |
| 6.7.1.1. Threshold value | 33 |
| 6.7.1.2. Switching output | 34 |
| 6.7.1.3. Block | 35 |
| 6.8. Humidity PI control | 36 |
| 6.8.0.1. General control | 36 |

| | |
|---|----|
| 6.8.0.2. Controller setpoint | 37 |
| 6.8.0.3. Dehumidification and/or humidification | 38 |
| 6.9. Dewpoint measurement | 39 |
| 6.9.1. Cooling medium temp. monitoring | 39 |
| 6.9.1.1. Threshold value | 39 |
| 6.9.1.2. Switching output | 40 |
| 6.9.1.3. Blocking | 40 |
| 6.10. Absolute humidity | 41 |
| 6.11. Comfort field | 42 |
| 6.12. CO ₂ parameter settings | 42 |
| 6.13. CO ₂ threshold values | 43 |
| 6.13.1. Threshold value 1, 2, 3, 4 | 43 |
| 6.13.1.1. Threshold value | 43 |
| 6.13.1.2. Switching output | 44 |
| 6.13.1.3. Block | 45 |
| 6.14. CO ₂ PI-control | 46 |
| 6.14.0.1. General control | 46 |
| 6.14.0.2. Controller setpoint | 46 |
| 6.14.0.3. Ventilation control | 47 |
| 6.15. Variable comparator | 48 |
| 6.15.1. Control variable comparator 1/2 | 48 |
| 6.16. Logic | 49 |
| 6.16.0.1. AND logic | 49 |
| 6.16.0.2. OR logic | 49 |
| 6.16.1. AND logic 1-4 and OR logic outputs 1-4 | 49 |
| 6.16.1.1. Block | 51 |
| 6.16.2. Connection inputs of the AND logic | 51 |
| 6.16.3. Connection inputs of the OR logic | 53 |



Installation, inspection, commissioning and troubleshooting of the device must only be carried out by a competent electrician.

This manual is amended periodically and will be brought into line with new software releases. The change status (software version and date) can be found in the contents footer. If you have a device with a later software version, please check **www.elsner-elektronik.de** in the menu area "Service" to find out whether a more up-to-date version of the manual is available.

Clarification of signs used in this manual



Safety advice.



Safety advice for working on electrical connections, components, etc.

DANGER!

... indicates an immediately hazardous situation which will lead to death or severe injuries if it is not avoided.

WARNING!

... indicates a potentially hazardous situation which may lead to death or severe injuries if it is not avoided.

CAUTION!

... indicates a potentially hazardous situation which may lead to trivial or minor injuries if it is not avoided.



ATTENTION! ... indicates a situation which may lead to damage to property if it is not avoided.

ETS

In the ETS tables, the parameter default settings are marked by underlining.

1. Description

The **Sensor KNX AQS/TH-UP gl CH** measures CO₂ concentration, temperature and humidity and calculates the dew point. The sensor can receive external measured values via the bus and process them with the own data to overall values (mixed values, e. g. room average).

The **KNX AQS/TH-UP gl CH** provides switching outputs with adjustable threshold values. The switching outputs and further communication objects can be linked by AND and OR logic gates. Additionally, an integrated actuating variable comparator can compare and output values that are received via communication objects.

Integrated PI controllers allows for control of a ventilation (depending on CO₂ concentration and air humidity) and a heating/cooling system (depending on temperature). The **KNX AQS/TH-UP gl CH** can emit a warning to the bus as soon as the area of optimum comfort (according to DIN 1946) is left.

The device is completed with a frame of the switching series installed in the building and thus merges with the interior.

Functions:

- Measurement of **CO₂ concentration** of the air, of **temperature** and **air humidity** (absolute and relative), calculation of the dew point
- **Mixed values** from own measured values and external values (proportions can be set in percentage)
- **PI controller for heating** (one or two step) and **cooling** (one or two step) depending on temperature. Control according to separate target values or basic target temperature
- **PI controller for ventilation** depending on humidity and CO₂ concentration: dehumidification/humidification (one step) or dehumidification (one or two step)
- **Threshold values** can be adjusted per parameter or via communication objects: 3 × temperature, 2 × humidity, 4 × CO₂
- **4 AND and 4 OR logic gates** with each 4 inputs. Every switching incident as well as 16 logic inputs in the form of communication objects, may be used as inputs for the logic gates. The output of each gate may optionally be configured as 1 bit or 2 × 8 bits
- **2 actuating variable comparators** for output of minimum, maximum or average values. Each with 5 inputs (for values received via communication objects)

Configuration is made using the KNX software ETS 5. The **product file** can be downloaded from the ETS online catalogue and the Elsner Elektronik website on www.elsner-elektronik.de in the "Service" menu.

1.0.1. Scope of delivery

- Housing
- Mounting adapter with screws

You will need *in addition* (not supplied):

- Inlet box
- Cover frame (for insert 60 x 60 mm) and mounting plate (77mm) for swiss installation standard

1.1. Technical specifications

| | |
|-----------------------------------|---|
| Housing | Real glass, plastic |
| Colours | <ul style="list-style-type: none"> • similar to RAL 9010 pure white • similar to RAL 9005 jet black |
| Mounting | Installation in inlet box |
| Protection category | IP 20 |
| Dimensions | Housing approx. 60 x 60 (W x H, mm), mounting depth approx. 8 mm, |
| Total weight | approx. 60 g |
| Ambient temperature | Operation 0...+50°C, storage -10...+60°C |
| Ambient air humidity | max. 95% RH, avoid bedewing |
| Operating voltage | KNX bus voltage |
| Bus current | max. 20 mA |
| Data output | KNX +/- bus terminal plug |
| BCU type | Own micro controller |
| PEI type | 0 |
| Group addresses | max. 254 |
| Allocations | max. 254 |
| Communication objects | 196 |
| CO ₂ measurement range | 300...5000 ppm |
| CO ₂ resolution | 1 ppm |
| Temperature measurement range | 0...+50°C |
| Temperature resolution | 0.1°C |
| Humidity measurement range | 0% RH ...95% RH |
| Humidity resolution | 0.1% |
| Humidity drift | ± 0.5% R.H. per year in normal air |

The product conforms with the provisions of EU guidelines.

1.1.1. Accuracy of the measurement

Measurement variations from permanent sources of interference (see chapter *Installation position*) can be corrected in the ETS in order to ensure the specified accuracy of the sensor (offset).

To ensure a correct **CO₂ measurement**, the device must be installed in a windproof socket. After applying the operating voltage, it can take up to 15 minutes until the **CO₂ measured value** is output correctly.

When **measuring temperature**, the self-heating of the device is considered by the electronics. The heating is compensated by the software.

2. Installation and commissioning

2.1. Installation notes



Installation, testing, operational start-up and troubleshooting should only be performed by an electrician.



CAUTION! **Live voltage!**

There are unprotected live components inside the device.

- National legal regulations are to be followed.
- Ensure that all lines to be assembled are free of voltage and take precautions against accidental switching on.
- Do not use the device if it is damaged.
- Take the device or system out of service and secure it against unintentional use, if it can be assumed, that risk-free operation is no longer guaranteed.

The device is only to be used for the intended purpose described in this manual. Any improper modification or failure to follow the operating instructions voids any and all warranty and guarantee claims.

After unpacking the device, check it immediately for possible mechanical damage. If it has been damaged in transport, inform the supplier immediately.

The device may only be used as a fixed-site installation; that means only when assembled and after conclusion of all installation and operational start-up tasks and only in the surroundings designated for it.

Elsner Elektronik is not liable for any changes in norms and standards which may occur after publication of these operating instructions.

2.2. Installation position

The **Sensor KNX AQS/TH-UP gI CH** is made for wall mounting in an inlet box. The device is supplemented with a frame of the 60 mm swiss installation standard.



May be installed and operated in dry interior rooms only.
Avoid condensation.

When selecting an installation location, please ensure that the measurement results are affected as little as possible by external influences. Possible sources of interference include:

- Direct sunlight
- Drafts from windows and doors
- Draft from ducts which lead from other rooms or from the outside to the junction box in which the sensor is mounted
- Warming or cooling of the building structure on which the sensor is mounted, e.g. due to sunlight, heating or cold water pipes
- Connection lines and ducts which lead from warmer or colder areas to the sensor

Measurement variations from permanent sources of interference can be corrected in the ETS in order to ensure the specified accuracy of the sensor (offset).

To ensure a correct CO₂ measurement, the device must be installed in a windproof socket.

2.3. Composition

2.3.1. Housing




Fig. 1

- 1 Mounting adapter with screws
- 2 Openings for air circulation
- 3 Catches
- 4 KNX terminal BUS +/-

- 5 Programming-LED (recessed)
- 6 Programming-Button (recessed) for teaching device

2.4. Assembly of the sensor

First of all fit the windproof inlet box with connection. Also seal inlet pipes to avoid infiltration.

Turn the screws a little way into the mounting adapter.




Fig. 2

Hook the mounting adapter into the mounting plate of the switch system and tighten the screws.




Fig. 3

Screw the mounting plate onto the inlet box

Position the frame of the switching programme. Connect the bus line +/- to the black-red plug.

Pin the housing with the notches on to the mounting adapter, so that device and frame are fixed. The device has to be inserted such that the bus terminal faces up (see Fig. 1). This is necessary for a correct temperature measurement.

2.5. Notes on mounting and commissioning

Never expose the device to water (e.g. rain) or dust. This can damage the electronics. You must not exceed a relative humidity of 95%. Avoid condensation.

After the bus voltage has been applied, the device will enter an initialisation phase lasting a few seconds. During this phase no information can be received or sent via the bus.

3. Addressing of the device at the bus

The device is supplied with the bus address 15.15.255. You can program another address into the ETS by overwriting the 15.15.255 address or by teaching via the programming button.

4. Disposal

After use, the device must be disposed of or recycled in accordance with the legal regulations. Do not dispose of it with the household waste!

5. Transfer protocol

Units:

Temperatures in degrees Celsius

Air humidity in %

Absolute air humidity in g/kg and/or g/m³

CO₂ content in ppm

Variables in %

5.1. List of all communications objects

Abbreviation flags:

C Communication

R Read

W Write

T Transfer

U Update

| No | Name | Function | Flags | Data Point Type | Size |
|----|--|------------------|----------|---------------------------|---------|
| 0 | Software version | readable | R-CT | [217.1] DPT_Version | 2 Bytes |
| 1 | Temperature/humidity malfunction sensor | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 2 | CO2 sensor malfunction | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 3 | Outside temperature reading | Input | -WC- | [9.1] DPT_Value_Temp | 2 Bytes |
| 4 | Inside temperature reading | Output | R-CT | [9.1] DPT_Value_Temp | 2 Bytes |
| 5 | Overall temperature reading | Output | R-CT | [9.1] DPT_Value_Temp | 2 Bytes |
| 6 | Min./max. temperature value request | Input | -WC- | [1.17] DPT_Trigger | 1 Bit |
| 7 | Minimum temperature reading | Output | R-CT | [9.1] DPT_Value_Temp | 2 Bytes |
| 8 | Maximum temperature reading | Output | R-CT | [9.1] DPT_Value_Temp | 2 Bytes |
| 9 | Reset min./max. temperature value | Input | -WC- | [1.17] DPT_Trigger | 1 Bit |
| 10 | Temp. threshold value 1: Absolute value | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 11 | Temp. threshold value 1: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 12 | Temp. threshold value 1: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |

| No | Name | Function | Flags | Data Point Type | Size |
|----|---|------------------|----------|---------------------------|---------|
| 13 | Temp. threshold value 1: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 14 | Temp. threshold value 1: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 15 | Temp. threshold value 1: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 16 | Temp. threshold value 2: Absolute value | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 17 | Temp. threshold value 2: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 18 | Temp. threshold value 2: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 19 | Temp. threshold value 2: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 20 | Temp. threshold value 2: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 21 | Temp. threshold value 2: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 22 | Temp. threshold value 3: Absolute value | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 23 | Temp. threshold value 3: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 24 | Temp. threshold value 3: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 25 | Temp. threshold value 3: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 26 | Temp. threshold value 3: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 27 | Temp. threshold value 3: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 29 | TR_1_ Eco-Standby HVAC 1 | Input | -WC- | [20.102] DPT_HVACMode | 1 Byte |
| 30 | TR_1_ Comfort Activation HVAC 2 | Input | RWC T | [20.102] DPT_HVACMode | 1 Byte |
| 31 | TR_1_ Frost/Heat activation | Input | RWC T | [1.1] DPT_Switch | 1 Bit |
| 32 | TR_1_ Blocking object (active at value = 1) | Input | -WC- | [1.1] DPT_Switch | 1 Bit |
| 33 | TR_1_ Target value, current | Output | R-CT | [9.1] DPT_Value_Temp | 2 Bytes |
| 34 | TR_1_ Switching object (0:Heat 1:Cool) | Input | -WC- | [1.1] DPT_Switch | 1 Bit |
| 35 | TR_1_ Target value, comfort heat- ing | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |

| No | Name | Function | Flags | Data Point Type | Size |
|----|---|------------------|----------|----------------------------|---------|
| 36 | TR_1_ Target value, comfort heating (1:+ 0:-) | Input | -WC- | [1.1] DPT_Switch | 1 Bit |
| 37 | TR_1_ Target value, comfort cooling | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 38 | TR_1_ Target value, comfort cooling (1:+ 0:-) | Input | -WC- | [1.1] DPT_Switch | 1 Bit |
| 39 | TR_1_ Target value_Basic offset 16 Bit | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 40 | TR_1_ Target value, Standby heating | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 41 | TR_1_ Target value, Standby heating (1:+ 0:-) | Input | -WC- | [1.1] DPT_Switch | 1 Bit |
| 42 | TR_1_ Target value, Standby cooling | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 43 | TR_1_ Target value, Standby cooling (1:+ 0:-) | Input | -WC- | [1.1] DPT_Switch | 1 Bit |
| 44 | TR_1_ Target value, Eco heating | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 45 | TR_1_ Target value, Eco heating (1:+ 0:-) | Input | -WC- | [1.1] DPT_Switch | 1 Bit |
| 46 | TR_1_ Target value, Eco cooling | Input/ Output | RWC T | [9.1] DPT_Value_Temp | 2 Bytes |
| 47 | TR_1_ Target value, Eco cooling (1:+ 0:-) | Input | -WC- | [1.1] DPT_Switch | 1 Bit |
| 48 | TR_1_ Control variable heating (stage 1) | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 49 | TR_1_ Control variable heating stage 2 | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 50 | TR_1_ Control variable cooling (stage 1) | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 51 | TR_1_ Control variable cooling stage 2 | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 52 | TR_1_ Status heating 1 (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 53 | TR_1_ Status heating 2 (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 54 | TR_1_ Cooling status 1 (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 55 | TR_1_ Cooling status 2 (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 56 | TR_1_ Comfort Delay Status | Input/ Output | RWC T | [1.1] DPT_Switch | 1 Bit |
| 57 | TR_1_ Comfort extension time (in sec) | Input/ Output | RWC T | [7.5] DPT_TimePeriodSec | 2 Bytes |

| No | Name | Function | Flags | Data Point Type | Size |
|----|---|------------------|----------|-----------------------------|---------|
| 58 | TR_1_Belimo_Control variable | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 59 | Outside humidity reading | Input | -WC- | [9.7] DPT_Value_Humidity | 2 Bytes |
| 60 | Inside humidity reading | Output | R-CT | [9.7] DPT_Value_Humidity | 2 Bytes |
| 61 | Overall humidity reading | Output | R-CT | [9.7] DPT_Value_Humidity | 2 Bytes |
| 62 | Min./max. humidity value request | Input | -WC- | [1.17] DPT_Trigger | 1 Bit |
| 63 | Minimum humidity reading | Output | R-CT | [9.7] DPT_Value_Humidity | 2 Bytes |
| 64 | Maximum humidity reading | Output | R-CT | [9.7] DPT_Value_Humidity | 2 Bytes |
| 65 | Reset min./max. humidity value | Input | -WC- | [1.17] DPT_Trigger | 1 Bit |
| 66 | Humidity threshold value 1: Absolute value | Input/ Output | RWC T | [9.7] DPT_Value_Humidity | 2 Bytes |
| 67 | Humidity threshold value 1: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 68 | Humidity threshold value 1: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 69 | Humidity threshold value 1: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 70 | Humidity threshold value 1: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 71 | Humidity threshold value 1: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 72 | Humidity threshold value 2: Absolute value | Input/ Output | RWC T | [9.7] DPT_Value_Humidity | 2 Bytes |
| 73 | Humidity threshold value 2: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 74 | Humidity threshold value 2: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 75 | Humidity threshold value 2: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 76 | Humidity threshold value 2: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 77 | Humidity threshold value 2: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 78 | Humidity controller: Blocking object | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 79 | Humidity controller: Target value | Input/ Output | RWC T | [9.7] DPT_Value_Humidity | 2 Bytes |

| No | Name | Function | Flags | Data Point Type | Size |
|----|--|----------|-------|------------------------------------|---------|
| 80 | Humidity controller: Target value (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 81 | Humidity controller: Control variable dehumidification (stage 1) | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 82 | Humidity controller: Control variable dehumidification stage 2 | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 83 | Humidity controller: Control variable humidification | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 84 | Humidity controller: Dehumidification 1 status (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 85 | Humidity controller: Dehumidification 2 status (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 86 | Humidity controller: Humidification status (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 87 | Dewpoint temperature | Output | R-CT | [9.1] DPT_Value_Temp | 2 Bytes |
| 88 | Coolant temp.: Threshold value | Output | R-CT | [9.1] DPT_Value_Temp | 2 Bytes |
| 89 | Coolant temp.: Actual value | Input | -WC- | [9.1] DPT_Value_Temp | 2 Bytes |
| 90 | Coolant temp.: Offset change (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 91 | Coolant temp.: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 92 | Coolant temp.: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 93 | Coolant temp.: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 94 | Coolant temp.: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 95 | Absolute humidity [g/kg] | Output | R-CT | [14.5] DPT_Value_Ampli- tude | 4 Bytes |
| 96 | Absolute humidity [g/m ³] | Output | R-CT | [14.17] DPT_Value_Density | 4 Bytes |
| 97 | Ambient climate status: 1 = comfortable 0 = uncomfortable | Output | R-CT | [1.2] DPT_Bool | 1 Bit |
| 98 | Outside CO2 reading | Input | -WC- | [9.8] DPT_Value_AirQua- lity | 2 Bytes |
| 99 | Inside CO2 Internal reading | Output | R-CT | [9.8] DPT_Value_AirQua- lity | 2 Bytes |

| No | Name | Function | Flags | Data Point Type | Size |
|-----|--|------------------|----------|-------------------------------|---------|
| 100 | Total CO2 reading | Output | R-CT | [9.8] DPT_Value_AirQuality | 2 Bytes |
| 101 | CO2 maximum value request | Input | -WC- | [1.17] DPT_Trigger | 1 Bit |
| 102 | Maximum CO2 reading | Output | R-CT | [9.8] DPT_Value_AirQuality | 2 Bytes |
| 103 | Reset CO2 maximum value | Input | -WC- | [1.17] DPT_Trigger | 1 Bit |
| 104 | CO2 threshold value 1: Absolute value | Input/ Output | RWC T | [9.8] DPT_Value_AirQuality | 2 Bytes |
| 105 | CO2 threshold value 1: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 106 | CO2 threshold value 1: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 107 | CO2 threshold value 1: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 108 | CO2 threshold value 1: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 109 | CO2 threshold value 1: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 110 | CO2 threshold value 2: Absolute value | Input/ Output | RWC T | [9.8] DPT_Value_AirQuality | 2 Bytes |
| 111 | CO2 threshold value 2: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 112 | CO2 threshold value 2: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 113 | CO2 threshold value 2: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 114 | CO2 threshold value 2: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 115 | CO2 threshold value 2: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 116 | CO2 threshold value 3: Absolute value | Input/ Output | RWC T | [9.8] DPT_Value_AirQuality | 2 Bytes |
| 117 | CO2 threshold value 3: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 118 | CO2 threshold value 3: Switching delay from 0 to 1 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |
| 119 | CO2 threshold value 3: Switching delay from 1 to 0 | Input | -WC- | [9.010] DPT_Value_Time | 2 Bytes |

| No | Name | Function | Flags | Data Point Type | Size |
|-----|--|------------------|----------|-------------------------------|---------|
| 120 | CO2 threshold value 3: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 121 | CO2 threshold value 3: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 122 | CO2 threshold value 4: Absolute value | Input/ Output | RWC T | [9.8] DPT_Value_AirQuality | 2 Bytes |
| 123 | CO2 threshold value 4: (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 124 | CO2 threshold value 4: Switching delay from 0 to 1 | Input | -WC- | [7.5] DPT_TimePeriodSec | 2 Bytes |
| 125 | CO2 threshold value 4: Switching delay from 1 to 0 | Input | -WC- | [7.5] DPT_TimePeriodSec | 2 Bytes |
| 126 | CO2 threshold value 4: Switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 127 | CO2 threshold value 4: Switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 128 | CO2 controller: Blocking object | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 129 | CO2 controller: Target value | Input/ Output | RWC T | [9.8] DPT_Value_AirQuality | 2 Bytes |
| 130 | CO2 controller: Target value (1:+ 0:-) | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 131 | CO2 controller: Control variable ventilation (stage 1) | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 132 | CO2 controller: Control variable ventilation (stage 2) | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 133 | CO2 controller: Ventilation 1 status (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 134 | CO2 controller: Ventilation 2 status (1=ON 0=OFF) | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 135 | Comparator 1 actuating variable: Input 1 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 136 | Comparator 1 actuating variable: Input 2 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 137 | Comparator 1 actuating variable: Input 3 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 138 | Comparator 1 actuating variable: Input 4 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 139 | Comparator 1 actuating variable: Input 5 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 140 | Comparator 1 actuating variable: Output | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |

| No | Name | Function | Flags | Data Point Type | Size |
|-----|--|----------|-------|----------------------|--------|
| 141 | Comparator 1 actuating variable: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 142 | Comparator 2 actuating variable: Input 1 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 143 | Comparator 2 actuating variable: Input 2 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 144 | Comparator 2 actuating variable: Input 3 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 145 | Comparator 2 actuating variable: Input 4 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 146 | Comparator 2 actuating variable: Input 5 | Input | -WC- | [5.1] DPT_Scaling | 1 Byte |
| 147 | Comparator 2 actuating variable: Output | Output | R-CT | [5.1] DPT_Scaling | 1 Byte |
| 148 | Comparator 2 actuating variable: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 149 | AND logic 1: 1-bit switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 150 | AND logic 1: 8-bit output A | Output | R-CT | [5] 5.xxx | 1 Byte |
| 151 | AND logic 1: 8-bit output B | Output | R-CT | [5] 5.xxx | 1 Byte |
| 152 | AND logic 1: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 153 | AND logic 2: 1-bit switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 154 | AND logic 2: 8-bit output A | Output | R-CT | [5] 5.xxx | 1 Byte |
| 155 | AND logic 2: 8-bit output B | Output | R-CT | [5] 5.xxx | 1 Byte |
| 156 | AND logic 2: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 157 | AND logic 3: 1-bit switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 158 | AND logic 3: 8-bit output A | Output | R-CT | [5] 5.xxx | 1 Byte |
| 159 | AND logic 3: 8-bit output B | Output | R-CT | [5] 5.xxx | 1 Byte |
| 160 | AND logic 3: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 161 | AND logic 4: 1-bit switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 162 | AND logic 4: 8-bit output A | Output | R-CT | [5] 5.xxx | 1 Byte |

| No | Name | Function | Flags | Data Point Type | Size |
|-----|------------------------------------|----------|-------|---------------------|--------|
| 163 | AND logic 4: 8-bit output B | Output | R-CT | [5] 5.xxx | 1 Byte |
| 164 | AND logic 4: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 181 | OR logic 1: 1-bit switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 182 | OR logic 1: 8-bit output A | Output | R-CT | [5] 5.xxx | 1 Byte |
| 183 | OR logic 1: 8-bit output B | Output | R-CT | [5] 5.xxx | 1 Byte |
| 184 | OR logic 1: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 185 | OR logic 2: 1-bit switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 186 | OR logic 2: 8-bit output A | Output | R-CT | [5] 5.xxx | 1 Byte |
| 187 | OR logic 2: 8-bit output B | Output | R-CT | [5] 5.xxx | 1 Byte |
| 188 | OR logic 2: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 189 | OR logic 3: 1-bit switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 190 | OR logic 3: 8-bit output A | Output | R-CT | [5] 5.xxx | 1 Byte |
| 191 | OR logic 3: 8-bit output B | Output | R-CT | [5] 5.xxx | 1 Byte |
| 192 | OR logic 3: Block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 193 | OR logic 4: 1-bit switching output | Output | R-CT | [1.1] DPT_Switch | 1 Bit |
| 194 | OR logic 4: 8-bit output A | Output | R-CT | [5] 5.xxx | 1 Byte |
| 195 | OR logic 4: 8-bit output B | Output | R-CT | [5] 5.xxx | 1 Byte |
| 196 | OR logic 4: switching output block | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 200 | Logic input 1 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 201 | Logic input 2 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 202 | Logic input 3 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 203 | Logic input 4 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |

| No | Name | Function | Flags | Data Point Type | Size |
|-----|----------------|----------|-------|-------------------|-------|
| 204 | Logic input 5 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 205 | Logic input 6 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 206 | Logic input 7 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 207 | Logic input 8 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 208 | Logic input 9 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 209 | Logic input 10 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 210 | Logic input 11 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 211 | Logic input 12 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 212 | Logic input 13 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 213 | Logic input 14 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 214 | Logic input 15 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |
| 215 | Logic input 16 | Input | -WC- | [1.2] DPT_Bool | 1 Bit |

6. Parameter setting

6.1. Behaviour on power failure/ restoration of power

Behaviour following a failure of the bus power supply:

The device sends nothing.

Behaviour on bus restoration of power and following programming or reset:

The device sends all outputs according to their send behaviour set in the parameters with the delays established in the "General settings" parameter block.

6.2. General settings

Set the basic data transfer characteristics and select whether or not malfunction objects should be sent.

| | |
|--|--|
| Send delay after power-up and programming for: | |
| Measured values | <u>5 s</u> • ... • 2 h |
| Threshold values and switching outputs | <u>5 s</u> • ... • 2 h |
| Controller objects | 5 s • <u>10 s</u> • ... • 2 h |
| Logic outputs | 5 s • <u>10 s</u> • ... • 2 h |
| Maximum telegram quota | <ul style="list-style-type: none"> • 1 message per second • ... • <u>5 messages per second</u> • ... • 20 messages per second |
| Use temp./humidity malfunction object | Yes • <u>No</u> |
| Use CO2 malfunction object | Yes • <u>No</u> |

6.3. Temperature value

Use **Offsets** to adjust the readings to be sent.

| | |
|-----------------|--------------------|
| Offset in 0,1°C | -50...50; <u>0</u> |
|-----------------|--------------------|

The unit can calculate a **mixed value** from its own reading and an external value. Set the mixed value calculation if desired. If an external value is used, all of the following settings are referred to the total value.

| | |
|--|---|
| Use external reading | Yes • <u>No</u> |
| Ext. Reading proportion of the total reading | 5% • 10% • ... • <u>50%</u> • ... • 100% |
| All of the following settings are referred to the total value. | |
| Send internal and total reading | <ul style="list-style-type: none"> • <u>never</u> • periodically • on change • on change and periodically |
| From change of (if sent on change) | <u>0,1°C</u> • 0,2°C • 0,5°C • ... • 5,0°C |
| Send cycle (if sent periodically) | <u>5 s</u> • 10 s • ... • 2 h |

The **minimum and maximum readings** can be saved and sent to the bus. Use the „Reset temperature min/max. value“ objects to reset the values to the current readings. The values are not retained after a reset.

| | |
|---------------------------|-----------------|
| Use minimum/maximum value | Yes • <u>No</u> |
|---------------------------|-----------------|

6.4. Temperature threshold values

Activate the required temperature threshold values. The menus for setting the threshold values are displayed.

| |
|---------------------------|
| Use threshold value 1/2/3 |
|---------------------------|

| |
|-----------------|
| Yes • <u>No</u> |
|-----------------|

6.4.1. Threshold value 1, 2, 3

Threshold value

Set, in which cases **threshold values** received via object are to be retained. The parameter is only taken into consideration if the setting via object is activated below. Please note that the setting "After power supply restoration and programming" should not be used for the initial start-up, as the factory settings are always used until the first communication (setting via objects is ignored).

Set the threshold value directly in the application program using parameters, or define them via the bus using a communication object.

Threshold value setting via parameter:

Set the threshold values and hysteresis directly.

| |
|-----------------------------|
| Threshold value setting via |
|-----------------------------|

| |
|--|
| Parameter • Communication objects |
|--|

| |
|--------------------------|
| Threshold value in 0.1°C |
|--------------------------|

| |
|--------------------------|
| -300 ... 800; <u>200</u> |
|--------------------------|

Threshold value setting via a communication object:

Define, how the threshold value is to be received from the bus. Basically, a new value can be received, or simply a command to increase or decrease.

During initial commissioning, a threshold value must be defined, which will be valid until the first communication with a new threshold value. For units which have already been taken into service, the last communicated threshold value can be used. Basically, a temperature range is given, in which the threshold value can be changed (object value limit).

A set threshold value will be retained until a new value or a change is transferred. The current value is saved, so that it is retained in the event of a power supply failure and will be available once the power supply is restored.

| |
|-----------------------------|
| Threshold value setting via |
|-----------------------------|

| |
|---|
| Parameter • Communication objects |
|---|

| |
|---|
| The value communicated last shall be maintained |
|---|

| |
|--|
| <ul style="list-style-type: none"> • <u>never</u> • after power supply restoration • after power supply restoration and programming |
|--|

| |
|--|
| Start threshold value in 0.1°C valid until first communication |
|--|

| |
|--------------------------|
| -300 ... 800; <u>200</u> |
|--------------------------|

| |
|-----------------------------------|
| Object value limit (min) in 0.1°C |
|-----------------------------------|

| |
|--------------------|
| <u>-300</u> ...800 |
|--------------------|

| |
|-----------------------------------|
| Object value limit (max) in 0.1°C |
|-----------------------------------|

| |
|--------------------|
| -300... <u>800</u> |
|--------------------|

| | |
|--|---|
| Type of threshold value change | <u>Absolute value</u> • Increase/decrease |
| Increment (upon increase/decrease change) | 0,1 °C • ... • 5°C, <u>1°C</u> |

Set the **hysteresis** independent of the type of threshold value specification.

| | |
|--|---------------------|
| Hysteresis in % of the threshold value | 0 ... 50; <u>20</u> |
|--|---------------------|

Switching output

Set the behaviour of the switching output when a threshold value is exceeded/undercut. The output switching delay can be set using objects or directly as a parameter.

| | |
|--|--|
| When the following conditions apply, the output is (TV = Threshold value) | <ul style="list-style-type: none"> • <u>TV above = 1</u> TV - hyst. below = 0 • <u>TV above = 0</u> TV - hyst. below = 1 • <u>TV below = 1</u> TV + hyst. above = 0 • <u>TV below = 0</u> TV + hyst. above = 1 |
| Delays can be set via objects (in seconds) | <u>No</u> • Yes |
| Switching delay from 0 to 1 (If delay can be set via objects: valid until 1st communication) | <u>None</u> • 1 s • 2 s • 5 s • 10 s • ... • 2 h |
| Switching delay from 1 to 0 (If delay can be set via objects: valid until 1st communication) | <u>None</u> • 1 s • 2 s • 5 s • 10 s • ... • 2 h |
| Switching output sends | <ul style="list-style-type: none"> • <u>on change</u> • on change to 1 • on change to 0 • on change and periodically • on change to 1 and periodically • on change to 0 and periodically |
| Cycle (only if sending periodically is selected) | <u>5 s</u> • 10 s • 30 s... • 2 h |

Block

The switching output can be blocked using an object.

| | |
|----------------------------|-----------------|
| Use switching output block | <u>No</u> • Yes |
|----------------------------|-----------------|

If the block is activated, define specifications here for the behaviour of the output when blocked.

| | |
|---|---|
| Analysis of the blocking object | <ul style="list-style-type: none"> • <u>At value 1: block</u> At value 0: release • At value 0: block At value 1: release |
| Blocking object value before 1st communication | <u>0</u> • 1 |
| Behaviour of the switching output | |
| On block | <ul style="list-style-type: none"> • <u>Do not send message</u> • send 0 • send 1 |

| | |
|--|---|
| On release (with 2 seconds release delay) | [Dependent on the "Switching output sends" setting] |
|--|---|

The behaviour of the switching output on release is dependent on the value of the parameter "Switching output sends" (see "Switching output")

| | |
|--|---|
| Switching output sends on change | <ul style="list-style-type: none"> • Do not send message • Send switching output status |
| Switching output sends on change to 1 | <ul style="list-style-type: none"> • Do not send message • if switching output = 1 → send 1 |
| Switching output sends on change to 0 | <ul style="list-style-type: none"> • Do not send message • if switching output = 0 → send 0 |
| Switching output sends on change and periodically | Send switching output status |
| Switching output sends on change to 1 and periodically | if switching output = 1 → send 1 |
| Switching output sends on change to 0 and periodically | if switching output = 0 → send 0 |

6.5. Temperature PI control

Activate the control if you want to use it.

| | |
|-------------|-----------------|
| Use control | <u>No</u> • Yes |
|-------------|-----------------|

General control

Set, in which cases **setpoint values and extension time** received via object are to be retained. The parameter is only taken into consideration if the setting via object is activated below. Please note that the setting "After power supply restoration and programming" should not be used for the initial start-up, as the factory settings are always used until the 1st communication (setting via objects is ignored).

For an adequate regulation of the indoor temperature, comfort, standby, eco and building protection modes may be used.

Comfort when present,

Standby during short absences,

Eco as a night-time mode and

Frost/heat protection (building protection) during longer absences.

The settings for the temperature control include the set point temperatures for the individual modes. Objects are used to determine which mode is to be selected. A change of mode may be triggered manually or automatically (e.g. by a timer, window contact).

The **mode** may be switched with two 8 bit objects of different priority. Objects

„... HVAC mode (Prio 2)“ for switching in everyday operation and

„... HVAC mode (Prio 1)“ for central switching with higher priority.

The objects are coded as follows:

- 0 = Auto
- 1 = Comfort
- 2 = Standby
- 3 = Eco
- 4 = Building Protection

Alternatively, you can use three objects, with one object switching between eco and standby mode and the two others activating comfort mode and frost/heat protection mode respectively. The comfort object blocks the eco/standby object, and the frost/heat protection object has the highest priority. Objects

„... Mode (1: Eco, 0: Standby)“,
 „... comfort activation mode“ and
 „... frost/heat protection activation mode“

| | |
|-----------------|---|
| Switch mode via | <ul style="list-style-type: none"> • two 8 Bit objects (HVAC Modes) • three 1 bit objects |
|-----------------|---|

Select the **mode to be activated after reset** (e.g. power failure, reset of the line via the bus) (Default).

Then configure a temperature control **block** via the blocking object.

| | |
|--|---|
| Mode after reset | <ul style="list-style-type: none"> • Comfort • <u>Standby</u> • Eco • Building protection |
| Behaviour of the blocking object with value | <ul style="list-style-type: none"> • <u>1 = Block</u> 0 = release • 0 = block 1 = release |
| Blocking object value before 1st communication | <u>0</u> • 1 |

Specify when the current **control variables** of the controller are to be **sent** to the bus. Periodic sending is safer, in case a message does not reach a recipient. You may also set up periodical monitoring by the actuator with this setting.

| | |
|---------------------------------|--|
| Send control variable | <ul style="list-style-type: none"> • <u>on change</u> • on change and periodically |
| from change (in % absolute) | 1...10; <u>2</u> |
| Cycle (if sent periodically) | 5 s • ... • <u>5 min</u> • ... • 2 h |

The **status object** reports the current status of the control variables (0% = OFF, >0% = ON) and may for example be used for visualisation, or to switch off the heating pump as soon as the heating is switched off.

| | |
|---------------------|--|
| Send status objects | <ul style="list-style-type: none"> • <u>on change</u> • on change to 1 • on change to 0 • on change and periodically • on change to 1 and periodically • on change to 0 and periodically |
|---------------------|--|

| | |
|---------------------------------|--------------------------------------|
| Cycle (if sent periodically) | 5 s • ... • <u>5 min</u> • ... • 2 h |
|---------------------------------|--------------------------------------|

Then define the **type of control**. Heating and/or cooling may be controlled in two levels.

| | |
|-----------------|---|
| Type of control | <ul style="list-style-type: none"> • <u>Single level heating</u> • <u>Dual-level heating</u> • <u>Single-level cooling</u> • <u>Single-level heating + single-level cooling</u> • <u>Dual-level heating + single-level cooling</u> • <u>Dual-level heating + dual-level cooling</u> |
|-----------------|---|

General set point values

You may enter separate set point values for each mode or use the comfort set point as a basic value.

If you are using the controls for both heating *and* cooling, you may also select the setting "separately with switching object". Systems used for cooling in the summer and for heating in the winter can thus be switched from one to the other.

If you are using the basic value, only the deviation from the comfort set point value is listed for the other modes (e. g., 2°C less for standby mode).

| | |
|--|---|
| Preserve modified set points after mode change | No • <u>Yes</u> |
| Setting the nominal values | <ul style="list-style-type: none"> • <u>separate with switching object</u> • <u>separate without switching object</u> • <u>with comfort set point as a basis</u> |

The grades for the set point changes is predefined. Modifications may only remain active temporarily (do not save) or remain saved even after voltage recovery (and programming). This also applies to a comfort extension.

| | |
|--|--|
| Grading for set point changes (in 0.1 °C) | 1... 50; <u>10</u> |
| Saving set point value(s) | not <ul style="list-style-type: none"> • <u>after voltage recovery</u> • <u>after voltage recovery and programming</u> |

The control may be manually reset to comfort mode from eco, or night mode. This allows the user to maintain the daily nominal value for a longer time, e.g. when having guests. The duration of this comfort extension period is set. After the comfort extension period is terminated, the system returns to eco mode.

| | |
|--|------------------------|
| Comfort extension time in seconds (can only be activated from eco mode) | 1...36000; <u>3600</u> |
|--|------------------------|

Set point Comfort

Comfort mode is usually used for daytime mode when people are present. A starting value is defined for the comfort set point as well as a temperature range in which the nominal value may be modified.

| | |
|---|------------------------|
| Initial heating/cooling set point (in 0.1 °C) valid till 1st communication <i>not upon saving the set point value after programming</i> | -300...800; <u>210</u> |
|---|------------------------|

If set point values are entered separately:

| | |
|---|------------------------|
| Min. object value heating/cooling (in 0.1 °C) | -300...800; <u>160</u> |
| Max. object value heating/cooling (in 0.1 °C) | -300...800; <u>280</u> |

If the comfort setpoint value is used as a basis:

If the comfort setpoint value is used as a basis, the reduction/increment of the value is set.

| | |
|--|------------------------|
| Starting heating/cooling setpoint (in 0.1 °C) valid until 1st communication | -300...800; <u>210</u> |
| Minimum base setpoint (in 0.1°C) | -300...800; <u>160</u> |
| Maximum base setpoint (in 0.1°C) | -300...800; <u>280</u> |
| Reduction by up to (in 0.1°C) | 0...100; <u>50</u> |
| Increase by up to (in 0.1°C) | 0...100; <u>50</u> |

If the comfort setpoint is used as the basis without a switching object, a dead zone is specified for the control mode "heating *and* cooling" to avoid direct switching from heating to cooling.

| | |
|--|--------------------|
| Dead zone between heating and cooling in 0,1°C <i>(only if both heating AND cooling are used)</i> | 1...100; <u>50</u> |
|--|--------------------|

Standby setpoint

Standby mode is usually used for daytime mode when people are absent.

If setpoint values are entered separately:

A starting setpoint value is defined as well as a temperature range in which the setpoint value may be changed.

| | |
|--|------------------------|
| Starting heating setpoint (in 0.1 °C) valid until 1st communication | -300...800; <u>180</u> |
| Starting heating setpoint (in 0.1 °C) valid until 1st communication | -300...800; <u>240</u> |

| | |
|--|------------------------|
| Min. object value heating/cooling (in 0.1 °C) | -300...800; <u>160</u> |
| Max. object value heating/cooling (in 0.1 °C) | -300...800; <u>280</u> |

If the comfort setpoint value is used as a basis:

If the comfort setpoint value is used as a basis, the reduction/increment of the value is set.

| | |
|---|--------------------|
| Reduce heating setpoint (in 0.1°C) (for heating) | 0...200; <u>30</u> |
| Increase cooling setpoint (in 0.1°C) (for cooling) | 0...200; <u>30</u> |

Eco setpoint

Eco mode is usually used for night mode.

If setpoint values are entered separately:

A starting setpoint value is defined as well as a temperature range in which the setpoint value may be changed.

| | |
|--|------------------------|
| Starting heating setpoint (in 0.1 °C) valid until 1st communication | -300...800; <u>160</u> |
| Starting cooling setpoint (in 0.1 °C) valid until 1st communication | -300...800; <u>280</u> |
| Min. object value heating/cooling (in 0.1 °C) | -300...800; <u>160</u> |
| Max. object value heating/cooling (in 0.1 °C) | -300...800; <u>280</u> |

If the comfort setpoint value is used as a basis:

If the comfort setpoint value is used as a basis, the reduction/increment of the value is set.

| | |
|---|--------------------|
| Reduce heating setpoint (in 0.1°C) (for heating) | 0...200; <u>50</u> |
| Increase cooling setpoint (in 0.1°C) (for cooling) | 0...200; <u>60</u> |

Setpoint values for frost/heat protection (building protection)

The building protection mode is for example used as long as windows are opened for ventilation. Setpoints for frost protection (heating) and heat protection (cooling) are determined which may not be modified from outside (no access via operating devices etc.). The building protection mode may be activated with delay, which allows you to leave the building before the controls switch to frost/heat protection mode.

| | |
|--------------------------------------|--|
| Setpoint frost protection (in 0.1°C) | -300...800; <u>70</u> |
| Activation delay | less than • 5 s • ... • <u>5 min</u> • ... • 2 h |

| | |
|-------------------------------------|---|
| Setpoint heat protection (in 0.1°C) | -300...800; <u>350</u> |
| Activation delay | none • 5 s • ... • <u>5 min</u> • ... • 2 h |

General control variables

This setting appears for the control types "Heating *and* Cooling" only. Here, you can decide whether to use a common control variable for heating and cooling. If the 2nd level has a common control variable, you also determine the control mode of the 2nd level here.

| | |
|--|--|
| For heating and cooling | <ul style="list-style-type: none"> • <u>separate control variables are used</u> • common control variables are used for Level 1 • common control variables are used for Level 2 • common control variable are used for Level 1+2 |
| Use control variable for 4/6-way valve (only for common control variables in level 1) | <u>No</u> • Yes |
| Control type (for level 2 only) | <ul style="list-style-type: none"> • 2-point-control • PI control |
| Control variable of the 2nd Level is on (only for level 2 with 2 point controlling) | <ul style="list-style-type: none"> • <u>1 bit object</u> • 8 bit object |

When using the control variable for a 4/6 way valve, the following applies:

0%...100% heating = 66%...100% control variable

OFF = 50% control variable

0%...100% cooling = 33%...0% control variable

6.5.1. Heating control level 1/2

If a heating control mode is configured, one or two setting sections for the heating levels are displayed.

In the 1st level, heating is controlled by a PI control, which allows to either enter control parameters or select predetermined applications.

In the 2nd level (therefore only in case of 2-level heating), heating is controlled via a PI or a 2-point-control.

In level 2, the setpoint difference between the two levels must also be specified, i.e. below which setpoint deviation the second level is added.

| | |
|---|---|
| Setpoint difference between 1st and 2nd level (in 0.1°C) (for level 2) | 0...100; <u>40</u> |
| Control type (for level 2, no common control variables) | <ul style="list-style-type: none"> • 2-point-control • PI control |

| | |
|---|--|
| Control variable is a <i>(for level 2 with 2-point controlling, no common control variables)</i> | <ul style="list-style-type: none"> • 1 bit object • 8 bit object |
|---|--|

PI control with control parameters:

This setting allows individual input of the parameters for PI control.

| | |
|------------------------------|---|
| Control type | <ul style="list-style-type: none"> • PI control |
| Setting of the controller by | <ul style="list-style-type: none"> • Controller parameter • specified applications |

Specify the deviation from the setpoint value at which the maximum control variable value is reached, i.e. the point at which maximum heating power is activated.

The reset time shows how quickly the controller responds to deviations from the setpoint value. In case of a short reset time, the control responds with a fast increase of the control variable. In case of a long reset time, the control responds somewhat less urgently and needs longer until the necessary control variable for the setpoint value deviation is reached.

You should set the time appropriate to the heating system at this point (observe manufacturer's instructions).

| | |
|--|--------------------|
| Maximum control variable is reached at setpoint/actual difference of (in °C) | 1... <u>5</u> |
| Reset time (in min.) | 1...255; <u>30</u> |

Now specify what should be sent when the control is blocked. Set a value greater 0 (=OFF) to receive a basic heating level, e.g. for floor heating.

On release, the control variable follows the rule again.

| | |
|---|---|
| When blocked, the control variable shall | <ul style="list-style-type: none"> • <u>not be sent</u> • send a specific value |
| Value (in %) <i>(if a value is sent)</i> | <u>0</u> ...100 |

In case of a common control variable for heating and cooling, 0 is always transmitted as a fixed value.

PI control with predetermined application:

This setting provides fixed parameters for frequent applications.

| | |
|--|--|
| Control type | <ul style="list-style-type: none"> • PI control |
| Setting of the controller by | <ul style="list-style-type: none"> • Controller parameter • specified applications |
| Application | <ul style="list-style-type: none"> • Warm water heating • Floor heating • Convection unit • Electric heating |
| Maximum control variable is reached at setpoint/actual difference of (in °C) | Warm water heating: 5 Floor heating: 5 Convection unit: 4 Electric heating: 4 |

| | |
|----------------------|---|
| Reset time (in min.) | Warm water heating: 150 Floor heating: 240 Convection unit: 90 Electric heating: 100 |
|----------------------|---|

Now specify what should be sent when the control is blocked. Set a value greater 0 (=OFF) to receive a basic heating level, e.g. for floor heating.

On release, the control variable follows the rule again.

| | |
|--|--|
| When blocked, the control variable shall | <ul style="list-style-type: none"> • not be sent • send a specific value |
| Value (in %) (if a value is sent) | <u>0</u> ...100 |

In case of a common control variable for heating and cooling, 0 is always transmitted as a fixed value.

2-point-control (only level 2):

2-point-control is used for systems which are only set to ON or OFF.

| | |
|--|--------------------------|
| Control type (is determined at a higher level for common control variables) | • 2-point-control |
|--|--------------------------|

Enter the hysteresis that prevents frequent on/off switching of temperatures in the threshold range.

| | |
|-----------------------|--------------------|
| Hysteresis (in 0.1°C) | 0...100; <u>20</u> |
|-----------------------|--------------------|

If separate control variables are used, select whether the control variable of the 2nd level is a 1 bit object (on/off) or an 8 bit object (on with percentage/off).

| | |
|------------------------------------|---|
| Control variable is a | <ul style="list-style-type: none"> • <u>1 bit object</u> • 8 bit object |
| Value (in %) (for 8 bit object) | 0... <u>100</u> |

Now specify what should be sent when the control is blocked. Set a value greater 0 (=OFF) to receive a basic heating level, e.g. for floor heating. On release, the control variable follows the rule again.

| | |
|--|--|
| When blocked, the control variable shall | <ul style="list-style-type: none"> • not be sent • send a specific value |
| Value (in %) only if a value is sent | <u>0</u> ...100 |

6.5.2. Cooling control level 1/2

If a cooling control mode is configured, one or two setting sections for the cooling levels are displayed.

In the 1st level, cooling is controlled by a PI control in which either control parameters can be entered or predetermined applications can be selected.

In the 2nd level (therefore only for 2-level cooling), cooling is controlled via a PI or a 2-point-control.

In level 2, the setpoint deviation between the two levels must also be specified, i.e. above which setpoint value deviation the second level is added.

| | |
|---|---|
| Setpoint difference between 1st and 2nd level (in 0.1°C) <i>(for level 2)</i> | 0...100; <u>40</u> |
| Control type <i>(for level 2, no common control variables)</i> | <ul style="list-style-type: none"> • 2-point-control • PI control |
| Control variable is a <i>(for level 2 with 2-point controlling, no common control variables)</i> | <ul style="list-style-type: none"> • <u>1 bit object</u> • 8 bit object |

PI control with control parameters:

This setting allows individual input of the parameters for PI control.

| | |
|------------------------------|---|
| Control type | • PI control |
| Setting of the controller by | <ul style="list-style-type: none"> • Controller parameter • specified applications |

Specify the deviation from the setpoint value which reaches maximum variable value, i.e. the point at which maximum cooling power is activated.

The reset time shows how quickly the controller responds to deviations from the setpoint value. In case of a short reset time, the control responds with a fast increase of the control variable. In case of a long reset time, the control responds somewhat less urgently and needs longer until the necessary control variable for the setpoint value deviation is reached. You should set the time appropriate to the cooling system at this point (observe manufacturer's instructions).

| | |
|--|--------------------|
| Maximum control variable is reached at setpoint/actual difference of (in °C) | 1... <u>5</u> |
| Reset time (in min.) | 1...255; <u>30</u> |

Now specify what should be sent when the control is blocked.

On release, the control variable follows the rule again.

| | |
|---|---|
| When blocked, the control variable shall | <ul style="list-style-type: none"> • <u>not be sent</u> • send a specific value |
| Value (in %) <i>(if a value is sent)</i> | <u>0</u> ...100 |

In case of a common control variable for heating and cooling, 0 is always transmitted as a fixed value.

PI control with predetermined application:

This setting provides fixed parameters for a cooling ceiling

| | |
|------------------------------|---|
| Control type | • PI control |
| Setting of the controller by | <ul style="list-style-type: none"> • Controller parameter • specified applications |

| | |
|--|---------------------|
| Application | • Cooling ceiling |
| Maximum control variable is reached at setpoint/actual difference of (in °C) | Cooling ceiling: 5 |
| Reset time (in min.) | Cooling ceiling: 30 |

Now specify what should be sent when the control is blocked.
On release, the control variable follows the rule again.

| | |
|--|--|
| When blocked, the control variable shall | <ul style="list-style-type: none"> • not be sent • send a specific value |
| Value (in %) (if a value is sent) | <u>0</u> ...100 |

2-point-control (only level 2):

2-point-control is used for systems which are only set to ON or OFF.

| | |
|---|--------------------------|
| Control type <i>is determined at a higher level for common variables</i> | • 2-point-control |
|---|--------------------------|

Enter the hysteresis that prevents frequent on/off switching of temperatures in the threshold range.

| | |
|-----------------------|--------------------|
| Hysteresis (in 0.1°C) | 0...100; <u>20</u> |
|-----------------------|--------------------|

If separate control variables are used, select whether the control variable of the 2nd level is a 1 bit object (on/off) or an 8 bit object (on with percentage/off).

| | |
|------------------------------------|---|
| Control variable is a | <ul style="list-style-type: none"> • <u>1 bit object</u> • 8 bit object |
| Value (in %) (for 8 bit object) | 0... <u>100</u> |

Now specify what should be sent when the control is blocked.
On release, the control variable follows the rule again.

| | |
|--|---|
| When blocked, the control variable shall | <ul style="list-style-type: none"> • <u>not be sent</u> • send a specific value |
| Value (in %) (if a value is sent) | <u>0</u> ...100 |

In case of a common control variable for heating and cooling, 0 is always transmitted as a fixed value.

6.6. Humidity measurement

Select (see 6.2.General settings), whether a **malfunction object** is to be sent if the sensor is faulty.

| | |
|------------------------|-----------------|
| Use malfunction object | <u>No</u> • Yes |
|------------------------|-----------------|

Use **Offsets** to adjust the readings to be sent.

| | |
|----------------|--------------------|
| Offset in % RH | -10...10; <u>0</u> |
|----------------|--------------------|

The unit can calculate a **mixed value** from its own reading and an external value. Set the mixed value calculation if desired. If an external portion is used, all of the following settings (threshold values, etc.) are related to the overall reading.

| | |
|--|---|
| Use external measured value | <u>No</u> • Yes |
| Ext. Reading proportion of the total reading | 5% • 10% • ... • <u>50%</u> • ... • 100% |
| All of the following settings are referred to the total value. | |
| Send internal and total reading | <ul style="list-style-type: none"> • <u>never</u> • periodically • on change • on change and periodically |
| At and above change of (if sent on change) | 0.1% RH • 0.2% RH • 0.5% RH • <u>1.0% RH</u> • ... • 25% RH |
| Send cycle (if sent periodically) | 5 s • <u>10 s</u> • ... • 2 h |

The **minimum and maximum readings** can be saved and sent to the bus. Use the „Reset humidity min/max value“ object to reset the values to the current readings. The values are not retained after a reset.

| | |
|-------------------------------|-----------------|
| Use minimum and maximum value | <u>No</u> • Yes |
|-------------------------------|-----------------|

6.7. Humidity threshold values

Activate the required air humidity threshold values. The menus for setting the threshold values are displayed.

| | |
|-------------------------|-----------------|
| Use threshold value 1/2 | Yes • <u>No</u> |
|-------------------------|-----------------|

6.7.1. Threshold value 1, 2

Threshold value

Set, in which cases **threshold values and delay times** received via objects are to be retained. The parameter is only taken into consideration if the setting via object is activated below. Please note that the setting "After power supply restoration and pro-

gramming" should not be used for the initial start-up, as the factory settings are always used until the first communication (setting via objects is ignored).

Set the threshold value directly in the application program using parameters, or define them via the bus using a communication object.

Threshold value setting using parameter:

Set the threshold values and hysteresis directly.

| | |
|--|--|
| Threshold value setting using | Parameter • Communication objects |
| Threshold value in % RH (valid until 1st communication) | 0 ... 100; <u>70</u> |

Threshold value setting using a communication object:

Define, how the threshold value is to be received from the bus. Basically, a new value can be received, or simply a command to increase or decrease.

During initial commissioning, a threshold value must be defined, which will be valid until the first communication with a new threshold value. For units which have already been taken into service, the last communicated threshold value can be used. Basically, a humidity range is specified in which the threshold value can be changed (object value limit).

A set threshold value will be retained until a new value or a change is transferred. The current value is saved, so that it is retained in the event of a power supply failure and will be available once the power supply is restored.

| | |
|---|--|
| Threshold value setting using | Parameter • Communication objects |
| The value communicated last shall be maintained | <ul style="list-style-type: none"> • <u>never</u> • after power supply restoration • after power supply restoration and programming |
| Starting threshold value in % RH valid until first communication | 0 ... 100; <u>70</u> |
| Object value limit (min.) in % RH | <u>0</u> ...100 |
| Object value limit (max.) in % RH | 0... <u>100</u> |
| Type of threshold value change | <u>Absolute value</u> • Increase/Decrease |
| Increment (upon increase/decrease change) | 1,00% • <u>2,00%</u> • 5,00% • 10,00% |

Set the **hysteresis** independent of the type of threshold value specification.

| | |
|---|---------------------|
| Hysteresis of the threshold value in % (relative to the threshold value) | 0 ... 50; <u>20</u> |
|---|---------------------|

Switching output

Set the behaviour of the switching output when a threshold value is exceeded/undercut. The output switching delay can be set using objects or directly as a parameter.

| | |
|---|--|
| When the following conditions apply, the output is (TV = Threshold value) | <ul style="list-style-type: none"> • <u>TV above = 1</u> <u>TV - hyst. below = 0</u> • <u>TV above = 0</u> <u>TV - hyst. below = 1</u> • <u>TV below = 1</u> <u>TV + hyst. above = 0</u> • <u>TV below = 0</u> <u>TV + hyst. above = 1</u> |
| Delays can be set via objects (in seconds) | <u>No</u> • Yes |
| Switching delay from 0 to 1 (If delay can be set via objects: valid until 1st communication) | <u>None</u> • 1 s • 2 s • 5 s • 10 s • ... • 2 h |
| Switching delay from 1 to 0 (If delay can be set via objects: valid until 1st communication) | <u>None</u> • 1 s • 2 s • 5 s • 10 s • ... • 2 h |
| Switching output sends | <ul style="list-style-type: none"> • <u>on change</u> • on change to 1 • on change to 0 • on change and periodically • on change to 1 and periodically • on change to 0 and periodically |
| Cycle (is only sent if periodically is selected) | <u>5 s</u> • 10 s • 30 s... • 2 h |

Block

The switching output can be blocked using an object.

| | |
|----------------------------|-----------------|
| Use switching output block | <u>No</u> • Yes |
|----------------------------|-----------------|

If the block is activated, define specifications here for the behaviour of the output when blocked.

| | |
|--|--|
| Analysis of the blocking object | <ul style="list-style-type: none"> • <u>At value 1: block</u> <u>At value 0: release</u> • <u>At value 0: block</u> <u>At value 1: release</u> |
| Blocking object value before first communication | <u>0</u> • 1 |
| Behaviour of the switching output | |
| On block | <ul style="list-style-type: none"> • <u>Do not send message</u> • send 0 • send 1 |
| On release (with 2 seconds release delay) | [Dependent on the "Switching output sends" setting] |

The behaviour of the switching output on release is dependent on the value of the parameter "Switching output sends" (see "Switching output")

| | |
|---------------------------------------|---|
| Switching output sends on change | <ul style="list-style-type: none"> • Do not send message • Send switching output status |
| Switching output sends on change to 1 | <ul style="list-style-type: none"> • Do not send message • if switching output = 1 → send 1 |

| | |
|--|---|
| Switching output sends on change to 0 | <ul style="list-style-type: none"> • Do not send message • if switching output = 0 → send 0 |
| Switching output sends on change and periodically | Send switching output status |
| Switching output sends on change to 1 and periodically | if switching output = 1 → send 1 |
| Switching output sends on change to 0 and periodically | if switching output = 0 → send 0 |

6.8. Humidity PI control

If you activate humidity control, you can use the following settings to define control type, setpoint values, and humidification and dehumidification.

| | |
|----------------------|-----------------|
| Use humidity control | <u>No</u> • Yes |
|----------------------|-----------------|

General control

Sensor KNX AQS/TH-UP gI CH can be used to control one- or two-level dehumidification or combined humidification/dehumidification.

| | |
|-----------------|--|
| Type of control | <ul style="list-style-type: none"> • <u>One-level dehumidification</u> • Two-level dehumidification • Humidification and dehumidification |
|-----------------|--|

Configure a block for the humidity control using the blocking object.

| | |
|--|---|
| Behaviour of the blocking object with value | <ul style="list-style-type: none"> • <u>1 = block control</u> 0 = release control • 0 = block control 1 = release control |
| Blocking object value before first communication | <u>0</u> • 1 |

Specify when the current control variables are to be sent to the bus. Periodic sending is safer, in case a message does not reach a recipient. You may also set up periodic monitoring using an actuator with this setting.

| | |
|--|--|
| Send control variable | <ul style="list-style-type: none"> • <u>on change</u> • on change and periodically |
| from change (in % absolute) | 1 ... 20, <u>2</u> |
| Send cycle (is only sent if "periodically" is selected) | 5 s • ... • <u>5 min</u> • ... • 2 h |

The status object shows the current status of the output variable (0 = OFF, >0 = ON) and can for example be used for visualisation.

| | |
|--|--|
| Send status object(s) | <ul style="list-style-type: none"> • <u>on change</u> • on change to 1 • on change to 0 • on change and periodically • on change to 1 and periodically • on change to 0 and periodically |
| Send cycle (is only sent if "periodically" is selected) | 5 s • ... • <u>5 min</u> • ... • 2 h |

Controller setpoint

Set, in which cases **setpoint values** received via object are to be retained. Please note that the setting "After power supply restoration and programming" should not be used for the initial start-up, as the factory settings are always used until the first communication (setting via objects is ignored).

During initial commissioning, a **setpoint value** must be defined which is valid until the first communication of a new setpoint value. For units which have already been taken into service, the last communicated setpoint value can be used. Basically, an air humidity range is specified in which the setpoint value can be changed (**object value limit**).

Enter, how the setpoint value will be received from the bus. Basically, a new value can be received, or simply a command to increase or decrease.

A set setpoint value will be retained until a new value or a change is transferred. The current value is saved, so that it is retained in the event of a power supply failure and will be available once the power supply is restored.

Setpoint value setting using parameter:

Set the threshold values and hysteresis directly.

| | |
|--|--|
| Setpoint value setting using | Parameter • Communication objects |
| Setpoint value in 0.1% RH (valid until 1st communication) | 0 ... 100; <u>70</u> |

Setpoint value setting using communication object:

| | |
|--|--|
| Setpoint value setting using | Parameter • Communication objects |
| The value communicated last shall be maintained | <ul style="list-style-type: none"> • <u>never</u> • after power supply restoration • after power supply restoration and programming |
| Start setpoint in % valid until first communication (not upon saving the setpoint value after programming) | 0 ... 100; <u>50</u> 0...100; <u>40</u> |
| Object value limit (min.) in % | 0...100; <u>60</u> |

| | |
|--------------------------------|---|
| Object value limit (max.) in % | <u>Absolutwert</u> • Anhebung / Absenkung |
| | 1,00% • 2,00% • <u>5,00%</u> • 10,00% |

In "Humidification and dehumidification" control mode, a dead zone is specified so that a direct changeover switching between humidification and dehumidification can be avoided.

| | |
|--|-------------------|
| Dead zone between humidification and dehumidification in % <i>(only if both humidification and dehumidification are used)</i> | 0...50; <u>15</u> |
|--|-------------------|

Humidification starts, when the relative air humidity is lower or equal to the setpoint value - dead zone value.

Dehumidification and/or humidification

Depending on the control mode, settings sections for humidification and dehumidification appear (level 1/2).

For dual-level dehumidification, the setpoint value difference between the two levels must be defined, i.e. the setpoint value which, when exceeded, triggers the switch to the 2nd level.

| | |
|---|-------------------|
| Target value difference between level 1 and 2 in % <i>(for level 2 only)</i> | 0...50; <u>15</u> |
|---|-------------------|

Determine the deviation from the setpoint value at which the maximum variable value is reached, i.e. the point at which maximum output is used.

The reset time shows how quickly the controller responds to deviations from the setpoint value. In case of a short reset time, the control responds with a fast increase of the control variable. In case of a long reset time, the control responds somewhat less urgently and needs longer until the necessary control variable for the setpoint value deviation is reached.

You should set the time appropriate for the humidification/dehumidification system at this point (note manufacturer instructions).

| | |
|--|-------------------|
| Maximum control variable is reached at target/actual difference of % | 1...50; <u>5</u> |
| Reset time in minutes | 1...255; <u>3</u> |

Now specify, what should be sent when the control is blocked.

On release, the control variable follows the rule again.

| | |
|---|---|
| When blocked, the control variable shall | <ul style="list-style-type: none"> • <u>not be sent</u> • send a specific value |
| Value in % <i>(if a value is sent)</i> | <u>0</u> ...100 |

6.9. Dewpoint measurement

The **Sensor KNX AQS/TH-UP gl CH** calculates the dewpoint temperature and can output the value to the bus.

| | |
|---|---|
| Use dewpoint temperature | <u>No</u> • Yes |
| Sending pattern | <ul style="list-style-type: none"> • <u>never</u> • periodically • on change • on change and periodically |
| At and above change of (if sent on change) | <u>0,1°C</u> • 0,2°C • 0,5°C • 1,0°C • 2,0°C • 5,0°C |
| Send cycle (if sent periodically) | <u>5 s</u> • 10 s • 30 s • 1 min • ... • 2 h |

Activate the monitoring of the coolant temperature if required. The menus for setting the monitoring are displayed.

| | |
|---|-----------------|
| Use monitoring of the coolant temperature | <u>No</u> • Yes |
|---|-----------------|

6.9.1. Cooling medium temp. monitoring

A threshold value can be set for the temperature of the coolant, which is based on the current dewpoint temperature (offset/deviation). The switching output of the coolant temperature monitoring system can provide a warning prior to any build-up of condensation in the system, and/or activate appropriate countermeasures.

Threshold value

Threshold value = dewpoint temperature + offset

Set, in which cases **offset** received via object is to be retained. Please note that the setting "After power supply restoration and programming" should not be used for the initial start-up, as the factory settings are always used until the first communication (setting via objects is ignored).

| | |
|--|--|
| The offset communicated last shall be maintained | <ul style="list-style-type: none"> • <u>never</u> • after power supply restoration • after power supply restoration and programming |
|--|--|

During initial commissioning, an **offset** must be defined which is valid until the first communication of a new offset. For units which have already been taken into service, the last communicated offset can be used.

A set offset will be retained until a new value or a change is transferred. The current value is saved, so that it is retained in the event of a power supply failure and will be available once the power supply is restored.

| | |
|--|---|
| Start offset in °C valid until first communication | 0...20; <u>3</u> |
| Increment for offset change via communication object | 0,1°C • 0,2°C • 0,3°C • 0,4°C • 0,5°C • <u>1°C</u> • 2°C • 3°C • 4°C • 5°C |
| Hysteresis of the threshold value in % (for setting in %) | 0 ... 50; <u>20</u> |
| Threshold value sends | <ul style="list-style-type: none"> • <u>never</u> • periodically • on change • on change and periodically |
| At and above change of (if sent on change) | <u>0.1°C</u> • 0.2°C • 0.5°C • 1.0°C • 2.0°C • 5.0°C |
| Send cycle (if sent periodically) | 5 s • <u>10 s</u> • 30 s • 1 min • ... • 2 h |

Switching output

The output switching delay can be set using objects or directly as a parameter.

| | |
|--|--|
| When the following conditions apply, the output is (TV = Threshold value) | <ul style="list-style-type: none"> • TV above = 1 TV - hyst. below = 0 • TV above = 0 TV - hyst. below = 1 • <u>TV below = 1 TV + hyst. above = 0</u> • TV below = 0 TV + hyst. above = 1 |
| Delays can be set via objects (in seconds) | <u>No</u> • Yes |
| Switching delay from 0 to 1 for setting via objects: valid until 1st communication | <u>None</u> • 1 s • 2 s • 5 s • 10 s • ... • 2 h |
| Switching delay from 1 to 0 for setting via objects: valid until 1st communication | <u>None</u> • 1 s • 2 s • 5 s • 10 s • ... • 2 h |
| Switching output sends | <ul style="list-style-type: none"> • <u>on change</u> • on change to 1 • on change to 0 • on change and periodically • on change to 1 and periodically • on change to 0 and periodically |
| Send cycle (is only sent if periodically is selected) | <u>5 s</u> • 10 s • 30 s... • 2 h |

Blocking

The switching output can be blocked using an object. Define specifications here for the behaviour of the output when blocked.

| | |
|--|---|
| Use switching output block | <u>No</u> • Yes |
| Analysis of the blocking object | <ul style="list-style-type: none"> • <u>At value 1: block</u> At value 0: release • At value 0: block At value 1: release |
| Blocking object value before first communication | <u>0</u> • 1 |
| Behaviour of the switching output | |
| On block | <ul style="list-style-type: none"> • <u>Do not send message</u> • send 0 • send 1 |
| On release (with 2 seconds release delay) | [Dependent on the "Switching output sends" setting] |

The behaviour of the switching output on release is dependent on the value of the parameter "Switching output sends" (see "Switching output")

| | |
|--|---|
| Switching output sends on change | <ul style="list-style-type: none"> • Do not send message • Send switching output status |
| Switching output sends on change to 1 | <ul style="list-style-type: none"> • Do not send message • if switching output = 1 → send 1 |
| Switching output sends on change to 0 | <ul style="list-style-type: none"> • Do not send message • if switching output = 0 → send 0 |
| Switching output sends on change and periodically | Send switching output status |
| Switching output sends on change to 1 and periodically | if switching output = 1 → send 1 |
| Switching output sends on change to 0 and periodically | if switching output = 0 → send 0 |

6.10. Absolute humidity

The absolute air humidity value is detected by the **KNX AQS/TH-UP gl CH** and can be output to the bus.

| | |
|---|---|
| Use absolute humidity | <u>No</u> • Yes |
| Sending pattern | <ul style="list-style-type: none"> • <u>never</u> • periodically • on change • on change and periodically |
| At and above change of (if sent on change) | 0,1 g • 0,2 g • 0,5 g • <u>1,0 g</u> • 2,0 g • 5,0 g |
| Send cycle (if sent periodically) | <u>5 s</u> • 10 s • 30 s... • 2 h |

6.11. Comfort field

The **Sensor KNX AQS/TH-UP gl CH** can send a message to the bus if the limits of the comfort field are exceeded. In this way, it is for example possible to monitor compliance with DIN 1946 (standard values) or even to define your own comfort field.

| | |
|-----------------------------------|---|
| Use comfort field | <u>No</u> • Yes |
| Sending pattern | <ul style="list-style-type: none"> • <u>never</u> • periodically • on change • on change and periodically |
| Send cycle (if sent periodically) | <u>5 s</u> • 10 s • 30 s... • 2 h |

Define the comfort field by specifying the minimum and maximum values for temperature and humidity. The specified standard values comply with DIN 1946

| | |
|--|------------------------|
| Maximum temperature in °C (Standard 26°C) | 25 ... 40; <u>26</u> |
| Minimum temperature in °C (Standard 20°C) | 10 ... 21; <u>20</u> |
| Maximum relative humidity in % (Standard 65%) | 52 ... 90; <u>65</u> |
| Minimum relative humidity in % (Standard 30%) | 10 ... 43; <u>30</u> |
| Maximum absolute humidity in 0.1 g/kg (Standard 115 g/kg) | 50 ... 200; <u>115</u> |

Temperature hysteresis: 1°C

Relative humidity hysteresis: 2% RH

Absolute humidity hysteresis: 2 g/kg

6.12. CO₂ parameter settings

Select (see *General settings*, Seite 20), whether a **malfunction object** is to be sent if the sensor is faulty.

| | |
|------------------------|-----------------|
| Use malfunction object | <u>No</u> • Yes |
|------------------------|-----------------|

Use **Offsets** to adjust the readings to be sent.

| | |
|---------------|----------------------|
| Offset in ppm | -100...100; <u>0</u> |
|---------------|----------------------|

The unit can calculate a **mixed value** from its own reading and an external value. Set the mixed value calculation if desired. If an external portion is used, all of the following settings (threshold values, etc.) are related to the overall reading.

| | |
|--|--|
| Use external measured value | <u>No</u> • Yes |
| Ext. Reading proportion of the total reading | 5% • 10% • ... • <u>50%</u> • ... • 100% |
| All of the following settings are referred to the total value. | |

| | |
|--|---|
| Sending pattern for internal and total measured value | <ul style="list-style-type: none"> • <u>never</u> • periodically • on change • on change and periodically |
| At and above change of (relative to the last measured value) (if sent on change) | 2% • <u>5%</u> • ... • 50% |
| Send cycle (if sent periodically) | <u>5 s</u> • 10 s • ... • 2 h |

The **maximum reading** can be saved and sent to the bus. Using the "Reset CO2 maximum value" objects, the value can be reset to the current reading. The value is not retained after a reset.

| | |
|-------------------|-----------------|
| Use maximum value | <u>No</u> • Yes |
|-------------------|-----------------|

6.13. CO2 threshold values

Activate the required CO2 threshold value. The menus for setting the threshold values are displayed.

| | |
|-----------------------------|-----------------|
| Use threshold value 1/2/3/4 | Yes • <u>No</u> |
|-----------------------------|-----------------|

300 ppm ... 1000 ppm: fresh air

1000 ppm ... 2000 ppm: used air

1000 ppm = 0.1 %

6.13.1. Threshold value 1, 2, 3, 4

Threshold value

Set, in which cases **threshold values and delay times** received via object are to be retained. The parameter is only taken into consideration if the setting via object is activated below. Please note that the setting "After power supply restoration and programming" should not be used for the initial start-up, as the factory settings are always used until the first communication (setting via objects is ignored).

Set the threshold value directly in the application program using parameters, or define them via the bus using a communication object.

Threshold value setting using parameters:

Set the threshold values and hysteresis directly.

| | |
|-------------------------------|--|
| Threshold value setting using | Parameter • Communication objects |
| Threshold value in ppm | 0 ... 5000; <u>1200</u> |

Threshold value setting using a communication object:

Define, how the threshold value will be received from the bus. Basically, a new value can be received, or simply a command to increase or decrease.

During initial commissioning, a threshold value must be defined, which will be valid until the first communication of a new threshold value. For units which have already been taken into service, the last communicated threshold value can be used. Basically, a range is specified in which the threshold value can be changed (object value limit).

A set threshold value will be retained until a new value or a change is transferred. The current value is saved, so that it is retained in the event of a power supply failure and will be available once the power supply is restored.

| | |
|--|--|
| Threshold value setting using | Parameter • Communication objects |
| The value communicated last shall be maintained | <ul style="list-style-type: none"> • <u>never</u> • after power supply restoration • after power supply restoration and programming |
| Start threshold value in ppm valid until first communication | 0 ... 5000; <u>1200</u> |
| Limitation of object value (min) in ppm | <u>0</u> ...5000 |
| Limitation of object value (max) in ppm | 0... <u>5000</u> ; <u>2000</u> |
| Type of threshold value change | <u>Absolute value</u> • Increase/Decrease |
| Increment in ppm (upon increase/decrease change) | 1 • 2 • 5 • 10 • <u>20</u> • ... • 200 |

Set the **hysteresis** independent of the type of threshold value specification.

| | |
|--|---------------------|
| Hysteresis in % of the threshold value | 0 ... 50; <u>20</u> |
|--|---------------------|

Switching output

Set the behaviour of the switching output when a threshold value is exceeded/undercut. The output switching delay can be set using objects or directly as a parameter.

| | |
|--|--|
| When the following conditions apply, the output is (TV = Threshold value) | <ul style="list-style-type: none"> • <u>TV above = 1 TV - hyst. below = 0</u> • <u>TV above = 0 TV - hyst. below = 1</u> • <u>TV below = 1 TV + hyst. above = 0</u> • <u>TV below = 0 TV + hyst. above = 1</u> |
| Delays can be set via objects (in seconds) | <u>No</u> • Yes |
| Switching delay from 0 to 1 (If delay can be set via objects: valid until first communication) | <u>None</u> • 1 s • 2 s • 5 s • 10 s • ... • 2 h |
| Switching delay from 1 to 0 (If delay can be set via objects: valid until first communication) | <u>None</u> • 1 s • 2 s • 5 s • 10 s • ... • 2 h |

| | |
|--|--|
| Switching output sends | <ul style="list-style-type: none"> • <u>on change</u> • on change to 1 • on change to 0 • on change and periodically • on change to 1 and periodically • on change to 0 and periodically |
| Cycle <i>(is only sent if periodically is selected)</i> | <u>5 s</u> • 10 s • 30 s... • 2 h |

Block

The switching output can be blocked using an object.

| | |
|----------------------------|-----------------|
| Use switching output block | <u>No</u> • Yes |
|----------------------------|-----------------|

If the block is activated, define specifications here for the behaviour of the output when blocked.

| | |
|--|---|
| Analysis of the blocking object | <ul style="list-style-type: none"> • <u>At value 1: block At value 0: release</u> • At value 0: block At value 1: release |
| Blocking object value before first communication | <u>0</u> • 1 |
| Behaviour of the switching output | |
| On block | <ul style="list-style-type: none"> • <u>Do not send message</u> • send 0 • send 1 |
| On release (with 2 seconds release delay) | [Dependent on the "Switching output sends" setting] |

The behaviour of the switching output on release is dependent on the value of the parameter "Switching output sends" (see "Switching output")

| | |
|--|---|
| Switching output sends on change | <ul style="list-style-type: none"> • Do not send message • Send switching output status |
| Switching output sends on change to 1 | <ul style="list-style-type: none"> • Do not send message • if switching output = 1 → send 1 |
| Switching output sends on change to 0 | <ul style="list-style-type: none"> • Do not send message • if switching output = 0 → send 0 |
| Switching output sends on change and periodically | Send switching output status |
| Switching output sends on change to 1 and periodically | if switching output = 1 → send 1 |
| Switching output sends on change to 0 and periodically | if switching output = 0 → send 0 |

6.14. CO2 PI-control

If you activate air quality control, you can use the following settings to define control type, setpoint values, and ventilation.

| | |
|-------------|-----------------|
| Use control | Yes • <u>No</u> |
|-------------|-----------------|

General control

The **Sensor KNX AQS/TH-UP gl CH** can be used to control one or two-stage ventilation.

| | |
|-----------------|---|
| Type of control | <ul style="list-style-type: none"> • <u>One-stage ventilation</u> • Two-stage ventilation |
|-----------------|---|

Configure a block for the ventilation control using the blocking object.

| | |
|--|--|
| Behaviour of the blocking object with value | <ul style="list-style-type: none"> • <u>1 = block control</u> <u>0 = release control</u> • 0 = block control 1 = release control |
| Blocking object value before first communication | 0 • <u>1</u> |

Specify when the current control variables are to be sent to the bus. Periodic sending is safer, in case a message does not reach a recipient. You may also set up periodic monitoring using an actuator with this setting.

| | |
|---------------------------------|--|
| Send control variable | <ul style="list-style-type: none"> • <u>on change</u> • on change and periodically |
| at and above change of (in ppm) | 1...20; <u>2</u> |
| Cycle (if sent periodically) | 5 s • ... • <u>5 min</u> • ... • 2 h |

The status object shows the current status of the output variable (0 = OFF, >0 = ON) and can for example be used for visualisation.

| | |
|---------------------------------|--|
| Send status object(s) | <ul style="list-style-type: none"> • <u>on change</u> • on change to 1 • on change to 0 • on change and periodically • on change to 1 and periodically • on change to 0 and periodically |
| Cycle (if sent periodically) | <u>5 s</u> • 10 s • ... • 2 h |

Controller setpoint

The setpoint values can be set directly in the application program using parameters, or be defined via the bus using a communication object.

Setpoint value setting using parameters:

Set the setpoint value directly.

| | |
|--------------------------|--|
| Specified setpoint using | Parameter • Communication objects |
| Target value in ppm | 300...5000; <u>800</u> |

Setpoint value setting via communication object:

Enter, how the setpoint value will be received from the bus. Basically, a new value can be received, or simply a command to increase or decrease.

During initial commissioning, a setpoint value must be defined which is valid until the first communication of a new setpoint value. For units which have already been taken into service, the last communicated setpoint value can be used. Basically, an air humidity range is given in which the setpoint value can be changed (object value limit).

A set setpoint value will be retained until a new value or a change is transferred. The current value is saved, so that it is retained in the event of a power supply failure and will be available once the power supply is restored.

| | |
|--|--|
| Threshold value setting using | Parameter • Communication objects |
| The last communicated value should be retained | <ul style="list-style-type: none"> • <u>never</u> • after power supply restoration • after power supply restoration and programming |
| Start setpoint value in ppm valid until first communication <i>(not upon saving the setpoint value after programming)</i> | 300... 5000; <u>800</u> |
| Object value limit (min) in ppm | 300...5000; <u>400</u> |
| Object value limit (max) in ppm | 300...5000; <u>1500</u> |
| Type of threshold value change | <u>Absolute value</u> • Increase/decrease |
| Increment in ppm <i>(upon increase/decrease change)</i> | 1 • 2 • 5 • ... • <u>20</u> • ... • 100 • 200 |

Ventilation control

Depending on the control mode, one and/or two setting sections for the ventilation stages are displayed.

For two-stage ventilation, the setpoint value difference between the two stages must be defined, i.e. the setpoint value which, when exceeded, triggers the switch to the 2nd level.

| | |
|---|------------------------|
| Target value difference between 1st and 2nd level in ppm <i>(for level 2 only)</i> | 100...2000; <u>400</u> |
|---|------------------------|

Determine the deviation from the setpoint value at which the maximum variable value is reached, i.e. the point at which maximum output is used.

The reset time shows how quickly the controller responds to deviations from the setpoint value. In case of a short reset time, the control responds with a fast increase of the control variable. In case of a long reset time, the control responds somewhat less urgently and needs longer until the necessary control variable for the setpoint value deviation is reached.

You should set the time appropriate to the ventilation system at this point (follow the manufacturer's instructions).

| | |
|---|--------------------|
| Maximum control variable is reached at setpoint value/actual difference of (in ppm) | <u>100</u> ...2000 |
| Reset time in minutes 1st level | 1...255; <u>30</u> |
| Reset time in minutes 2nd level | 1...255; <u>10</u> |

Now specify what should be sent when the control is blocked.

On release, the control variable follows the rule again.

| | |
|--|--|
| When blocked, the control variable shall | <ul style="list-style-type: none"> • <u>not send anything</u> • send a value |
| Value in % (if a value is sent) | <u>0</u> ...100 |

6.15. Variable comparator

The two integrated control variable comparators can output maximum, minimum and median values.

| | |
|--------------------|-----------------|
| Use comparator 1/2 | <u>No</u> • Yes |
|--------------------|-----------------|

6.15.1. Control variable comparator 1/2

Determine what the control variable comparator should output, and activate the input objects to be used. Send behaviour and blocks can also be set.

| | |
|---|---|
| Output delivered | <ul style="list-style-type: none"> • Maximum value • Minimum value • <u>Average value</u> |
| Use input 1/2/3/4/5 | No • Yes |
| Output sends | <ul style="list-style-type: none"> • <u>on change of output</u> • on change of output and periodically • when receiving an input object • when receiving an input object and periodically |
| From change of (is only sent if "on change" is selected) | <u>1%</u> • 2% • 5% • 10% • 20% • 25% |
| Send cycle (is only sent if "periodically" is selected) | 5 s • 10 s • 30 s • ... • <u>5 min</u> • ... • 2 h |

| | |
|--|--|
| Analysis of the blocking object | <ul style="list-style-type: none"> • at value 1: block at value 0: release • at value 0: block at value 1: release |
| Blocking object value before 1st communication | 0 • 1 |
| Behaviour of the switching output | |
| With blocking | <ul style="list-style-type: none"> • <u>do not send message</u> • Send value |
| Sent value in % | 0 ... 100 |

6.16. Logic

The device has 16 logic inputs, four AND- and four OR-logic gates.

Activate the logic inputs and assign object values up to 1st communication. Then, activate the required logic outputs.

| | |
|---|-----------------|
| Use logic inputs | Yes • <u>No</u> |
| Object value before 1st communication for | |
| - Logic input 1 | <u>0</u> • 1 |
| - Logic input ... | <u>0</u> • 1 |
| - Logic input 16 | <u>0</u> • 1 |

Activate the required logic outputs.

AND logic

| | |
|---------------|----------------------------|
| AND logic 1 | <u>not active</u> • active |
| AND logic ... | <u>not active</u> • active |
| AND logic 4 | <u>not active</u> • active |

OR logic

| | |
|--------------|----------------------------|
| OR logic 1 | <u>not active</u> • active |
| OR logic ... | <u>not active</u> • active |
| OR logic 4 | <u>not active</u> • active |

6.16.1. AND logic 1-4 and OR logic outputs 1-4

The same setting options are available for AND and OR logic.

Each logic output may transmit one 1 bit or two 8 bit objects. Determine what the output should send if logic = 1 and = 0.

| | |
|-------------------------|--|
| 1. / 2. / 3. / 4. Input | <ul style="list-style-type: none"> • <u>do not use</u> - Logic inputs 1...16 - Logic inputs 1...16 inverted • all switching events that the device provides (see <i>Connection inputs of the AND/OR logic</i>) |
| Output type | <ul style="list-style-type: none"> • a <u>1-Bit-object</u> • two 8-bit objects |

If the **output type is a 1-bit object**, set the output values for the various conditions.

| | |
|------------------------------|--------------|
| Output value if logic = 1 | <u>1</u> • 0 |
| Output value if logic = 0 | 1 • <u>0</u> |

If the **output type is two 8-bit objects**, set the type of object and the output values for the various conditions.

| | |
|---------------------------------------|--|
| Object type | <ul style="list-style-type: none"> • Value (0...255) • Percent (0...100%) • Angle (0...360°) • Scene call-up (0...127) |
| Output value object A if logic = 1 | 0 ... 255 / 100% / 360° / 127; <u>1</u> |
| Output value object B if logic = 1 | 0 ... 255 / 100% / 360° / 127; <u>1</u> |
| Output value object A if logic = 0 | 0 ... 255 / 100% / 360° / 127; <u>0</u> |
| Output value object B if logic = 0 | 0 ... 255 / 100% / 360° / 127; <u>0</u> |

Set the output send pattern.

| | |
|--------------------------------------|---|
| Send pattern | <ul style="list-style-type: none"> • <u>on change of logic</u> • on change of logic to 1 • on change of logic to 0 • on change of logic and periodically • on change of logic to 1 and periodically • on change of logic to 0 and periodically • on change of logic+object receipt • on change of logic+object receipt and periodically |
| Send cycle (if sent periodically) | 5 s • <u>10 s</u> • ... • 2 h |

Block

If necessary, activate the block for the logic output and set what a 1 or 0 at the block input means and what happens in the event of a block.

| | |
|--|--|
| Analysis of the blocking object | <ul style="list-style-type: none"> • <u>At value 1: block</u> <u>At value 0: release</u> • <u>At value 0: block</u> <u>At value 1: release</u> |
| Blocking object value before first call | <u>0</u> • 1 |
| Behaviour of switching output | |
| On block | <ul style="list-style-type: none"> • <u>Do not send message</u> • <u>Transmit block value</u> [see above, Output value if blocking active] |
| On release (with 2 seconds release delay) | [send value for current logic status] |

6.16.2.Connection inputs of the AND logic

do not use

Logic input 1

Logic input 1 inverted

Logic input 2

Logic input 2 inverted

Logic input 3

Logic input 3 inverted

Logic input 4

Logic input 4 inverted

Logic input 5

Logic input 5 inverted

Logic input 6

Logic input 6 inverted

Logic input 7

Logic input 7 inverted

Logic input 8

Logic input 8 inverted

Logic input 9

Logic input 9 inverted

Logic input 10

Logic input 10 inverted

Logic input 11

Logic input 11 inverted

Logic input 12

Logic input 12 inverted

Logic input 13

Logic input 13 inverted

Logic input 14

Logic input 14 inverted

Logic input 15

Logic input 15 inverted

Logic input 16
Logic input 16 inverted
Temperature/Humidity sensor malfunction = ON
Temperature/Humidity sensor malfunction = OFF
CO2 sensor malfunction ON
CO2 sensor malfunction OFF
Switching output temperature 1
Switching output temperature 1 inverted
Switching output temperature 2
Switching output temperature 2 inverted
Switching output temperature 3
Switching output temperature 3 inverted
Comfort temperature controller active
Comfort temperature controller inactive
Eco temperature controller active
Eco temperature controller inactive
Standby temperature controller active
Standby temperature controller inactive
Temperatur controller frost/heat active
Temperatur controller frost/heat inactive
Temp. control status heating 1
Temp. control status heating 1 inverted
Temp. control status heating 2
Temp. control status heating 2 inverted
Temp. control status cooling 1
Temp. control status cooling 1 inverted
Temp. control status cooling 2
Temp. control status cooling 2 inverted
Switching output humidity 1
Switching output humidity 1 inverted
Switching output humidity 2
Switching output humidity 2 inverted
Humidity control status dehumidification 1
Humidity control status dehumidification 1 inv.
Humidity control status dehumidification 2
Humidity control status dehumidification 2 inv.
Humidity control status humidification
Humidity control status humidification inverted
Switching output coolant temperature
Switching output coolant temperature inverted
Switching output cooling medium temperature
Switching output cooling medium temperature inv.
Switching output room climate status
Switching output room climate status inverted
Switching output CO2 1
Switching output CO2 1 inverted
Switching output CO2 2
Switching output CO2 2 inverted

Switching output CO2 3
Switching output CO2 3 inverted
Switching output CO2 4
Switching output CO2 4 inverted
CO2 controller status ventilation 1
CO2 controller status ventilation 1 inverted
CO2 controller status ventilation 2
CO2 controller status ventilation 2 inverted

6.16.3. Connection inputs of the OR logic

The OR logic connection inputs correspond to those of the AND logic. In addition the following inputs are available for the OR logic:

AND logic 1
AND logic output 1 inverted
AND logic output 2
AND logic output 2 inverted
AND logic output 3
AND logic output 3 inverted
AND logic output 4
AND logic output 4 inverted



Elsner Elektronik GmbH Control and Automation Engineering

Sohlengrund 16
75395 Ostelsheim
Germany

Phone +49 (0) 70 33 / 30 945-0 info@elsner-elektronik.de
Fax +49 (0) 70 33 / 30 945-20 www.elsner-elektronik.de

Technical support: +49 (0) 70 33 / 30 945-250